



SCU5 Upgrade or Retrofit Kit

Product and User Manual

Copyright Information

All of the information herein is the exclusive proprietary property of Roll-2-Roll Technologies LLC, and is disclosed with the understanding that it will be retained in confidence and will neither be duplicated nor copied in whole or in part nor be used for any purpose other than for which it is disclosed.

Information in this document is believed to be reliable and accurate. However no responsibility is assumed as a result of its use nor for any inaccuracies, infringement of patent or other rights of third parties resulting from its use.

The information in this document is subject to change without any notice.

CONTENTS

INTRODUCTION	5
Working Principle	5
Web Position Sensor	5
Controller	5
Guide Mechanism	6
Key Features	6
Product Description	6
General Specification	7
SAFETY INSTRUCTIONS	8
Instructions for Use	8
Proper Use	8
Improper Use	8
Pinch Points	8
Static Discharges and Grounding	9
INSTALLATION	10
Sensor	10
Physical Dimensions of ARIS WPS 16	12
Physical Dimensions of ARIS WPS 48	12
Physical Dimensions of ARIS WPS 221	13
Sensor Configuration and Terminologies	13
Web Guide Controller	14
Physical Dimensions of SCU5	14
Power Input	15
Prewiring	15
Switchcraft DC Connector	15
Industrial DIN Rail Power Supply	15
Grounding	16
Sensor Interface	16
Motor Communication	16
Industrial Ethernet Interface	16
Actuator and Servo Center Assembly	17
Nema 23 Actuator Mounting Bracket	17
Servo Center Sensor Mounting Bracket	18
Installing the Actuator and Servo Center Assembly	18
Microstepping Driver	19
Wiring	21
Wiring information for terminal block P1:	21

Wiring information for terminal block P5:	21
Wiring information for terminal block P5 with Lock/Run Signal Switch:	22
OPERATION AND OPERATOR INTERFACE	23
Main Operator Interface Screen	23
Automatic/Manual Operation	23
Servo-Centering Operation	24
Jog-left/Jog-right Operation	25
Guide Point Adjustment	26
Fine Guide Point Adjustment	26
Gross Guide Point Adjustment	27
Reset Guide Point	28
Web Position Indicators	29
Web Detected Indicator	29
Sensor Position Indicator	29
Find Sensor Button	30
Communication Indicator	30
Advanced Settings	30
Password Screen	30
Motor Speed	31
Minimum Contrast	32
Edge/Contrast Web Position Sensing	32
Web Width	33
Analog Output	33
Digital Output	33
Remote Control and Monitoring	36
Output registers	36
Sensor status and fault registers	36
Sensor position output register	37
Quality factor registers	38
Web guide status and fault registers	38
Guide point percentage	40
Diagnostic index	40
Motor speed percentage	40
Sensor input registers	40
Sensor command register	41
Web guide command register	41
Guide point offset register	43
Motor speed register	43
Communication Module	44
IP Address	44

Finding the IP Address	44
Setting a static IP address for the controller	45
COMMISSIONING	47
General Maintenance	47
TROUBLESHOOTING	48
APPLICABLE MODELS	49
Sensor	49
Control Unit	49
TECHNICAL SUPPORT AND SERVICE	50
Contact information	50
Return shipping instructions	50
REVISION HISTORY	51
Document Revision	51
Hardware Revision	51
Firmware Revision	51

INTRODUCTION

This product manual provides information about installation, use and maintenance of SCU5 web guide retrofit kit. The kit is designed to upgrade existing web guides with the latest sensor and control technologies offered by Roll-2-Roll Technologies. The upgrade involves the replacement of the sensor(s), actuator (pneumatic or hydraulic or electro mechanical), controller (electrical or pneumatic) while retaining the existing web guide mechanism.

The kit is designed for use in indoor industrial and laboratory equipment that process materials in web form as they move through a converting or raw material manufacturing process.

Working Principle

There are three main components to a web guiding system:

1. Web position sensor
2. Controller
3. Guide mechanism




Fig. 1: Components of a web guiding system

Web Position Sensor

The web position sensor provides the vision for the control system. The sensor measures the position of the web (edge or a contrasting feature on the web) and sends that information to the controller for corrective action.

Controller

The controller is the brain for the control system. Based on the sensor measurement the controller determines the corrective action necessary to accurately align the web material.

Guide Mechanism

The web guide mechanism is the muscle for the control system. The guide mechanism actuated by a motor physically steers/displaces the web to the required position based on the command from the controller.

Key Features

- **Simplicity:** The simplest web guide to install, operate and maintain.
- **No setup or re-calibration:** The intelligent control system adapts automatically to physical characteristics of the web material and web transport conditions to provide best performance without the need for re-tuning.
- **Plug-and-play system:** The sophisticated technologies within the system make the web guide simple to operate. There is no need to (1) select the type of sensor, (2) change controller gains, (3) change sensitivity, or (4) perform any calibration. Everything is done automatically. Just connect the power and sensor to start guiding the web.

Product Description

The sensor, controller and the actuator can be integrated into existing web guides for retrofit purposes. An illustration of the components of the retrofit kit is shown in Fig. 2.




Fig. 2: Key Components of the SCU5 retrofit kit

There are four basic components of the retrofit kit:

1. **Sensor:** The sensor head houses the LED light source, the optics and the camera sensor. The sensor head is connected to the web guide controller through a shielded cable secured by a cable gland.

The sensor head assembly is mounted onto an off-shelf aluminum rail (igus drylin N low profile linear rails with using NW-22-17-40 carriage) on web guide and is secured by M3 thumb screws.

2. **Web Guide Controller:** The controller powers the sensor, processes the image captured by the sensor, computes the necessary corrective action and commands the actuator to position the web guide to the desired location to control the web position. A 24 VDC power source is needed to power the web guide controller and the maximum power consumption is about 5 Amps (depending on the actuator).
3. **Operator Interface:** The touch screen operator interface enables the interaction between the web guide and operators. The screen also provides visual indication of the various operations of the web guiding system.
4. **Actuator:** The linear hybrid stepper motor actuates the web guide mechanism. A servo center sensor that monitors the position of the actuator can be used to home the web guide mechanism to the servo center position.
5. **Motor Driver:** A microstepping stepper driver powers the actuator by converting the commands from the controller into electric pulses to move the stepper actuator. The output from the servo center sensor is also processed by the motor driver.

NOTE: For high thrust applications several actuator options are available.

General Specification

Input Supply	24 V DC	Current	Less than 5 Amps ¹
Operator Interface	Optional color touchscreen	Languages	Language independent
Motor	Linear hybrid stepper	Maximum Thrust	Upto 1800 N ¹
Controller Frequency	50 Hz	Connectivity	Ethernet/IP, PROFINET
Maximum Speed	Up to 75 mm/sec	Nominal Travel	± 19 mm
Sensor Type	Fiber optic	Sensor Resolution	0.0635 mm or 0.125 mm
Sensor Range	16 mm, 48 mm or 221 mm	Accuracy	> 99.2%

¹ Off-the-shelf higher thrust actuators (with higher current requirements) are available for high thrust applications

SAFETY INSTRUCTIONS

The web guiding system, retrofitted with the SCU5 Retrofit Kit, is an electromechanical device that operates on low voltage (24 V DC). However, it does present a few safety requirements that must be followed in order to assure safe operation of the system.

Instructions for Use

The web guiding system must be properly transported, stored before being installed professionally. The guide should not be installed or commissioned for operation if any visible damage is observed. Only persons who have the necessary qualifications should work on the installation, commissioning, operation, and maintenance of the web guide.

Notes:

- Please read the product manual and properly follow its instructions
- Please read and follow the warning labels on the device
- Be aware of all national, state, and local requirements for accident prevention and environmental protection.

Proper Use

The SCU5 Retrofit Kit is intended for indoor uses only. The sensor and controller are designed for use in industrial and lab equipment that process materials in web form.

Improper Use

- The sensor uses high powered LED light source (visible or invisible) that may be harmful to human eye. Staring directly at the light source may harm vision and should be avoided.
- Outdoor use is considered improper.
- Any use outside the general specifications shall be considered improper use and voids any warranty of the equipment.
- Any replacement parts or modification necessities for the SCU5 Retrofit Kit should be made by Roll-2-Roll Technologies LLC.

Pinch Points

- Depending on the web guide mechanism the gap between top roller platform and the base region may have pinch points. The force of the actuator motor can cause damage to body parts due to crushing if these are caught in a pinch point.
- The gap between the rollers and the roller support plates must be considered a pinch point. The guide rollers are not powered and are only driven by the friction of the web. However, while the material is threaded and transported over the guide rollers this creates pinch points between the web and the roller. Under no circumstance should the roller or the web be touched while the web is transported.
- Any installation, maintenance, or inspection work on or around the web guide must be performed when the power to the web guide is turned off or unplugged. It is recommended that caution should be exercised when handling the web guide under power to avoid having body parts caught in the pinch points.

- Please follow standard Lockout/Tagout procedure while performing any function near the web guide.
- Care should be taken when handling the guide during shipping, transportation, or installation to avoid crushing of body parts or of other equipment from impact due to mishandling of the guide and to avoid personal injury. The web guide system should be securely and properly assembled before placing it in operation. Internal safety rules should be observed during the assembly process.
- The web guide with the SCU5 Retrofit Kit is an automatic control device that may stop and start at any time without notice, especially when controlled remotely. Hence standard safeguards must be in place to prevent any kind of injury.

Static Discharges and Grounding

- Web, especially plastic webs, when transported over rollers can create significant static voltage potential. This potential needs to safely discharged by proper grounding.
- The electronic elements of the web guiding system are sensitive to static discharges. Make sure that the web guiding system, the power supply, and the machine on which the web guide operates is properly grounded to avoid shock and the effect of static discharge.
- A grounding connector on the web guide and the controller may be used to safely ground the electronics within the web guiding system.

INSTALLATION

There are four main components of the retrofit kit: (1) a sensor head, (2) web guide controller with the operator interface, (3) actuator, and (4) microstepping driver.

Sensor

The sensor head houses the LED light source, the optics and the camera sensor. The sensor head is connected to the controller unit through a 12 conductor shielded cable secured by a cable gland. The sensor head assembly is mounted onto an off-shelf aluminum sensor rail (igus drylin N low profile linear rails with using NW-22-17-40 carriage) secured by M3 thumb screws as shown below. Other options for mounting are also available upon request. All these elements are factory shipped assembled as a ready to install unit.



Fig.3: Sensor Head Assembly with Mounting Rail

- The sensor rail has pre-drilled M3 clearance holes every 60 mm. These holes can be used to mount the sensor rail at a location downstream of the web guide.
- Each sensor slide carriage will have a locking M3 thumbscrew. Unscrew both thumbscrews to allow the carriage to slide in the rail.
- The sensor face has a acrylic filter lid. Make sure that the filter lid faces the web material when the sensor assembly is slid into the sensor rail.
- Carefully slide the sensor carriages into the sensor slide.
- Once the sensor has been installed in the sensor slide, install the plastic end caps (NSKB-17) on the ends of the rail.

Attention:

- The sensor rail should be positioned such that the sensor is at the downstream span of the web guide as shown in Fig. 1.
- The sensor should be installed such that the web material is about 5 to 12 mm from the filter lid for the most accurate measurement (See Fig. 4).
- The length of the sensor should be parallel to the width of the web and the sensor should be positioned normal to the plane of the web.
- The standard convention for the sensor is such that the bottom of the sensor has the cable gland nut and the left/right side are oriented while facing the sensor (as shown in Fig. 3).




Fig.4: Sensor Installation Considerations

WARNING: Even though the sensor working distance is less than 25 mm, the sensor operation may be affected by any object in the field of view of the sensor which is at a distance of 150 mm. Make sure that no object is present within this safe field of view range to ensure proper operation of the sensor (see Fig. 4).

WARNING: The infrared light source is invisible to the naked eye. Please do not stare directly into the sensor at any time. This can potential damage eyesight and may cause blindness.

WARNING: The white light source is visible to the naked eye. Please do not stare directly into the sensor at any time. This can potential damage eyesight.

WARNING: The ultraviolet light source may be visible or invisible to the naked eye. Please do not stare directly into the sensor at any time. This can potential damage eyesight and may cause blindness. Avoid any skin exposure with the ultraviolet light source. The exposure may be potentially harmful.

Three different sensor size options are currently available; the size corresponds to the sensing range. The physical dimensions of the sensor head, the assembly and the rail are shown next.

Physical Dimensions of ARIS WPS 16




Fig. 5: 16mm Sensor Head Assembly Dimensions (All Dimensions are in mm)

Physical Dimensions of ARIS WPS 48




Fig. 6: 48mm Sensor Head Assembly Dimensions (All Dimensions are in mm)

Physical Dimensions of ARIS WPS 221





Fig.7: 221mm Sensor Head Assembly Dimensions (All Dimensions are in mm)

Sensor Configuration and Terminologies

The sensor configuration and terminologies for proper installation and use of the sensor is provided in this section.



Left Sensor

Right Sensor

Fig. 8: Sensor Orientation Terminologies

The front view of the sensor is the orientation in which the cable gland is at the bottom while viewing the filter on the sensor. The front view of the sensor is shown above.

- Left Sensor: Looking at the front view of the sensor with the web between the observer and the sensor, if the sensor is positioned to the left edge of the web the orientation corresponds to a left sensor. This orientation is shown above.
- Right Sensor: When the sensor is positioned to the right edge of the web the orientation corresponds to a right sensor.

The sensor orientation can be automatically detected by the intelligent web guide controller whenever a sensor is plugged into the controller or when the find sensor option is used.

Web Guide Controller

The web guide controller encloses the electronic hardware for the sensor processing, operator interface and the control algorithm for the web guide/actuator. The control options that are available are shown below.



Fig. 9: SCU Controller Options

The most basic controller is the SCU5 MD which has the operator interface integrated within the controller. The option with C(x) includes the industrial ethernet option where both EtherNet/IP (C(E)) and PROFINET (C(P)) are supported. Finally, the controller can also be purchased without the display, in that case the web guide can be controlled through a PLC using the industrial ethernet communication.

Physical Dimensions of SCU5




Fig. 10: SCU5 Controller Physical Dimensions (All dimensions are in mm); Subject to change without notice.

The SCU5 controller has the following ports available for operation.




Fig. 11: SCU5 Connector Ports

Power Input

The retrofit kit operates under 24 VDC ($\pm 5\%$) power with a maximum current of 5 Amps. There are two power port options available: (1) pre-wired or (2) power jack connector based on the order.

Prewiring

In the pre-wired option, the unit may come with a 2.5 meter long power cable (through a gland nut) for the customer to connect to an appropriately grounded 24 VDC power source. There are three conductors in the power cable. The red colored conductor is the 24V power, the black colored conductor is the DC return or electronic circuit ground.

Switchcraft DC Connector

Sealed Switchcraft L712AS power jack port option is available on the SCU5. A mating Switchcraft 761KS12 plug connector or a pre-assembled Switchcraft CARA761KS07984 or a pre-assembled Switchcraft CA761KS07984 can be used to supply power. For the plug connector the 24 VDC power should be supplied to the tip/center pin and electronic ground on the sleeve pin. For the cable assembly the 24 VDC should be connected to the red cable and the electronic ground connected to the black cable.

Industrial DIN Rail Power Supply

Industrial DIN rail mountable power supply such as Mean Well SDR-75-24 can be used to supply the 24VDC power. This is an available purchase option.

Grounding

For safety and for normal operation, the web guide, the equipment to which the web guide is installed must be properly grounded. The controller should also be appropriately grounded. The metal enclosure surface or the mounting screws may be used to properly earth ground the controller.

WARNING: Please use all possible options to safely earth ground the web guide and the controller. Improper grounding may result in static buildup that can potentially result in malfunction of the web guiding system and the controller.

Sensor Interface

Two sensor ports labeled Sensor 1 and Sensor 2 have industry standard 12-pin M12 connectors to connect the 12-pin connector on the sensor cable. Either sensor ports can be used to connect the sensor(s) and the controller will automatically recognize the connection.

WARNING: The connectors are key and please do not force the connectors.

NOTE: If two sensors are connected the web guide will automatically configure the appropriate guiding mode based on the sensor installation. If both the left and the right edge is seen by the sensor, the center guiding mode will be enabled. If both the sensors see the same edge of the web then an average of the sensor measurement will be used to guide the web.

WARNING: Only the sensors and cables provided by Roll-2-Roll Technologies LLC should be connected to the sensor ports. Third-party cables and sensors may damage the controller and will void warranty.

Motor Communication

A 4-pin M8 connector is provided to connect the controller to the actuation system installed on the web guide mechanism. The pre-wired cable with the 4-pin M8 connector from the web guide mechanism should be connected to the motor communication cable. The motor communication cable carries the power and the communication signals between the SCU5 controller and the motor driver.

WARNING: Never connect or disconnect the motor communication cable while the SCU5 is powered or connected to a power supply. Always power down the SCU5 controller during the connection/disconnection operation.

WARNING: Only the cables provided by Roll-2-Roll Technologies LLC should be connected to the motor communication port. Third-party cables and sensors may damage the controller and will void warranty.

Industrial Ethernet Interface

An optional industrial ethernet connection to the web guiding system is available on controller models with suffix C(E) or C(P). A 4-pin D-coded M12 socket connect is provided for ethernet connection. Standard network cables such as Phoenix Contact NBC-MSD/ 1,0-93E/R4AC SCO - 1407360 or VS-MSD-IP20-93E/5,0 - 1403500 can be used to connect the ARIS SCU to an ethernet network using RJ45 plug.




Fig.12: 4- Pin Industrial Ethernet Connector.

A set of input and output registers are available to monitor and control the ARIS SCU.

Actuator and Servo Center Assembly

A standard off-the-shelf actuator is provided with the retrofit kit. The supplied actuator is a Nema 23 linear hybrid actuator from Haydon Kerk. Two linear thrust options of 333 N (57H42-3.25-815) and 900 N (57H4A-3.25-815) are provided based on the application need. Typical stroke length for the actuators are 1.5" while other stroke length options are also available upon request. The actuator dimension information from Haydon Kerk are provided below for reference.




Fig. 13: Actuator Dimension Information

Nema 23 Actuator Mounting Bracket

The retrofit kit is supplied with a Nema 23 mounting bracket and the required hardware to mount the actuator. The physical dimensions of the mounting bracket is shown in Fig. 14.




Fig. 14: Actuator Mounting Bracket (All Dimensions in mm)

Servo Center Sensor Mounting Bracket

Along with the actuator mounting bracket, a servo center mounting bracket is also provided to mount a M8 inductive proximity sensor. The dimensions of the mounting bracket is shown below.




Fig. 15: Servo Center Sensor Mounting Bracket (All Dimensions in mm)

Installing the Actuator and Servo Center Assembly

The actuator mounting bracket and the servo center mounting bracket can be installed on the machine frame using M4 screws. The recommended hole mounting pattern for the four M4 threaded holes should form a

rectangular pattern with 40 mm x 35.65 mm as the center-to-center distances. The before and after picture of the assembly is shown below.



Fig. 16: The Components of the Actuator and Servo Center Sensor Assembly




Fig. 17: Fully Assembled View of Actuator and Servo Center Sensor Assembly

The M6 threaded ends of the actuator can be used to couple the actuator and the web guide mechanism using a suitable coupling such as a High Load Ball Joint Rod End. Other mounting options are also possible. Please consult Roll-2-Roll Technologies LLC for other options.

Microstepping Driver

A DIN rail mountable microstepping driver is the standard driver option for the retrofit kit. The actuation commands from the SCU5 is converted into electrical pulses by the microstepping driver. The servo center functionality is also enabled by the microstepping driver.




Fig. 18: Physical Dimensions of the Microstepping Driver (All dimensions in mm)

The standard mounting option is the DIN rail mounting using the supplied base latch. Optionally wall mounting is also possible with the wall mounting holes. The dimensions are shown below.




Fig. 18: DIN Rail and Wall Mounting Options

Wiring

The microstepping driver has two terminal blocks (P1 and P5) to wire the 4-wire motor communication cable from the SCU5, 4-wire actuator cable and 3-wire servo center cable. Optionally a dry contact Lock/Run switch may also be connected (if enabled in the software) to disable the guide if the switch is open. The pin connections for the two terminal blocks for the standard option are shown below.

Wiring information for terminal block P1:

Pin	Function	Pin	Function	Pin	Function	Pin	Function
1	VDD (RD)	2	GND (BK)	3	RS485 A+ (GR)	4	RS485 B-(WH)
5	OB2 (RD)	6	OB1 (RD/WH)	7	OA2 (GR)	8	OA1 (GR/WH)

Wiring information for terminal block P5:

Pin	Function	Pin	Function	Pin	Function	Pin	Function
1	GND (BL)	2	VDD (BR)	3	NC	4	NC
5	NC	6	NC	7	NC	8	IN_3 (BK)

Legend

R: Red, BK: Black, BL: Blue, GR: Green, WH: White
BR: Brown, (RD/WH): Red/White, (GR/WH): Green/White

WARNING: Never connect or disconnect the motor wiring while the motor driver and/or the SCU5 is connected to a power supply.

WARNING: Never connect or disconnect the motor communication cable while the SCU5 is powered or connected to a power supply. Always power down the SCU5 controller during the connection/disconnection operation.

WARNING: Only the cables provided by Roll-2-Roll Technologies LLC should be connected to the motor communication port. Third-party cables and sensors may damage the controller and will void warranty.


WARNING: Please check the wiring thoroughly before connecting the power supply. Improper wiring may lead to damage to the actuator, the motor driver or the servo center sensor.

Lock/Run Signal Switch:

A three conductor cable (such as Alpha Wire 1213C) which connects to a dry contact switch which can stop the functionality of the web guide is also available. This functionality can be used to lock the web guide in

place when the external switch is open. For safety of the operators, please follow standard Lockout/Tagout procedure while performing any function near the web guide.

The functional wiring diagram to implement this functionality is shown on the right. In a typical installation the Red and White conductors should be connected to one terminal of the dry contact switch and the Black conductor to the other terminal of the dry contact switch. Whenever the switch is closed the guide will function normally. And whenever the switch is open then the web control controller will stop sending commands to the actuator thereby preventing the motion of the web guide.



In case the case where there is no need for a guide lock switch, all the three conductors can be shorted to enable the web guide to operator normally all the time.

Wiring information for terminal block P5 with Lock/Run Signal Switch:

Pin	Function	Pin	Function	Pin	Function	Pin	Function
1	GND (BL) GND (BK)	2	VDD (BR)	3	NC	4	NC
5	NC	6	IN_1 (RD)	7	IN_2 (WT)	8	IN_3 (BK)

Legend

R: Red, BK: Black, BL: Blue, GR: Green, WH: White

NOTE: When both the servo center connector and the Lock/Run functionality are enabled please make sure to connect the respective cables appropriately.

NOTE: Lock/Run Signal Switch is a standard feature in most software versions. If this feature is not used then Pin 6 and Pin 7 on P5 must be connected to ground for the actuator to move. If these are left floating the actuator will not move.

NOTE: In Lock/Run Signal Switch connection the color of the cables does not matter. Cables connected to Pin 6 and Pin 7 should always be shorted. And whenever these pins are both disconnected from GND the web guide actuator will be locked.

OPERATION AND OPERATOR INTERFACE

Main Operator Interface Screen

The web guide operation is accomplished through the main operator interface located on the web guide. The interface uses a language independent, icon based screen that allows ease of operation. Fig. 19 shows an image of the Operator Interface screen:



Fig.19: ARIS Operator Interface (Manual Mode)

The interface is a capacitive touch screen panel. Never use sharp or pointed tools of any kind to operate the interface. Best practice is to have operators use their fingers to press the different icons. Care must be taken to clean the touch screen surface periodically.

Its icon based design allows for a language independent operation without the need of translation of the screen for setup and operation in different countries.

Automatic/Manual Operation



Manual



Automatic

The web guide can be put into manual or automatic operation mode by pressing this icon. The guide is in manual operation when the icon is red and is in automatic mode when the icon is green. When the guide is in manual mode and the icon is pressed, the guide will switch to automatic mode. When the guide is in automatic mode and the icon is pressed the guide will be put into manual mode.

- The guide should be placed in manual operation during initial setup of the guide, or during routine maintenance of the production line.
- The guide must be placed in automatic operation when the production line is in production mode.

WARNING: Changing from one mode to another can result in change in the web guide position causing process upsets. Caution must be exercised when changing the operating mode and should be done by those who completely understand the consequence of this change.

WARNING: No personnel should be manually handling the web guide or the material around the web guide when the guide is in automatic operation. Failure to follow this warning could result in crushing of body parts at pinch points around and within the web guiding system.

WARNING: Care must be taken that only one person is working on the guide when it is in manual operation. Failure to follow this warning could result in crushing of body parts at pinch points around and within the web guiding system.

A few icons on the operator interface are enabled or disabled as the web guide is switched between manual and automatic mode based on the available options in each mode. Fig. 20 shows the operator interface while the web guiding system is in automatic mode. The advanced setup and sensing mode icons are disabled.



Fig. 20: ARIS Operator Interface (Automatic Mode)

Servo-Centering Operation



Servo-centering off



Servo-centering on

The servo-centering operation automatically centers the guide roller assembly of the guide.

- During normal operation the icon will be red.
- Upon pressing the icon, the icon turns green and the guide automatically moves the rollers to a factory preset center position. Once centered the icon returns to red indicating that it has finished the procedure and that servo-centering is off.


The servo center feature allows the guide to be centered quickly to facilitate threading of the web during changeover.

WARNING: Servo centering operation result in change in the web guide position causing process upset. Caution must be exercised when performing this function and should be done by those who completely understand the consequence of this change.

WARNING: Servo centering can be performed only when the web guiding system is in manual mode. Pressing the servo center icon during automatic operation will perform a different function.

WARNING: This is an automatic procedure of the web guiding system. No personnel should be performing manual work on or around the guide during the servo-centering procedure. Failure to follow this warning could result in crushing of body parts at pinch points around and within the web guiding system.

Jog-left/Jog-right Operation



The Jog-left/Jog-right icons allow the operator to manually move the guide roller assembly to the left or to the right as needed. These operations can be performed only when the web guide is in manual operating mode.

- The Jog-left/Jog-right operation icon indicates the operation is off when the icon is red.
- When the operator turns the Jog-left or Jog-right ON by pressing the icon, the guide will start moving to the left or right position. The respective icon will turn green during the Jog operation and will turn back to red when the operation is stopped.

The Jog operation can be stopped at any time by pressing the respective icon any time during the jog. If the guide reaches the extreme position, the jog operation will stop automatically. This operation can only be performed when the guide is in manual setting.

The left position of the guide is defined as the left side of the guide if the operator is viewing the guide from the downstream position (facing the sensor). Similarly, the right position of the guide is defined as the right side of the guide if the operator is viewing the guide from the downstream position.

WARNING: Jog-Left and Jog-Right operations result in change in the web guide position causing process upset. Caution must be exercised when performing these function and should be done by those who completely understand the consequence of this change.

WARNING: Jog-Left and Jog-Right operation can be performed only when the web guiding system is in manual mode. Pressing the icons during automatic operation will perform a different function.

WARNING: This is a manual procedure of the web guiding system. No personnel should be performing work on or around the guide during the jog procedure. Failure to follow this warning could result in crushing of body parts at pinch points around and within the web guiding system.

Guide Point Adjustment

The guide point of the web guiding system (reference or the desired location of the web with respect to the sensor) is set to 50% of the sensing window of the sensor when shipped from the factory. In this setting the web will be guided to a position exactly in the middle of the sensing window. The guide point can be adjusted to a different location within the sensor range. This setting is absolute irrespective of the sensor position. The current guide point setting is indicated by the guide point indicator as shown in Fig. 21.




Fig. 21: Guide Point Indicator

The visual guide point indicator is a track bar that provides an easy and quick visual indication of the web edge position with respect to the current guide point. Under normal conditions, the web position should align with the guide point while the web guide is in automatic control mode. A numerical guide point indicator displays the numerical value of the guide point offset on the screen.

The guide point can be adjusted in two ways: fine guide point adjustment for small incremental adjustments and gross guide point adjustment for large step change to the guide point.

Fine Guide Point Adjustment

The fine adjustments to the guide point can only be made when the web guide is in automatic mode. These adjustments enable small incremental changes to the guide through the operator interface to enable

operators to move the desired guiding position of the web. The fine adjustment to the guide point can be made by pressing the left (-) or right (+) arrow icons on the operator interface while the web guiding system is in automatic mode. Every single touch of the left or right icon will respectively decrease or increase the guide point by 0.256 mm. This change is immediately displayed by the visual guide point indicator and the numerical guide point indicator. Pressing the middle icon (servo-centering icon) will reset the guide point to 50% or 0 mm guide point offset.



Fig. 22: Fine guide point adjustment

Gross Guide Point Adjustment

The gross guide point adjustment is intended for making a large step change in the guide point, often after a product changeover especially with a web width change. This adjustment can be made by directly sliding the visual guide point indicator track bar to the desired location; the track bar can be moved only when the web guide is in manual mode.



Fig. 23: Gross guide point adjustment

The change in the guide point needs to be confirmed by pressing the “Accept” button that appears whenever the track bar is moved. The confirmation is intended to prevent any accidental changes to the guide point. If

the guide point change is not accepted within 10 seconds the change will be disregarded and the previously accepted guide point will be restored.

NOTE: The pressing of the Left (-) or Right (+) during fine guide point adjustment will momentarily change the icon to green as shown in Fig. 22. With the release of the button the icon changes the color back to red.

WARNING: The guide point adjustment operation result in change in the web guide position causing process upset. Caution must be exercised when performing this function and should be done by those who completely understand the consequence of this change.

WARNING: Fine guide point adjustment can be performed only when the web guiding system is in automatic mode. Pressing the Left (-) or Right (+) icons during manual operation will perform the jog operations.

WARNING: Guide point adjustment should be made only if it is necessary and should be carried out by personnel with good knowledge about the consequences of the change. The performance of the guiding system may deteriorate if the guide point is too far away from the desired 50% setting. Some of the changes might have no effect if the web guide is in an extreme position.

Reset Guide Point

The reset guide point is intended to quickly change the guide point to the current web position. The feature is used in applications with frequent web width changes. Instead of manually moving the guide point using the gross or fine guide point adjustment, the guide point can be reset to the current edge position with the press of a button. When in manual mode, pressing the reset guide point button will automatically set the new guide point to the current sensor location as shown in Fig. 24.



Fig. 24: Guide point reset

The change in the guide point needs to be confirmed by pressing the “Accept” button that appears whenever the reset guide point button is pressed. The confirmation is intended to prevent any accidental changes to the guide point. If the guide point change is not accepted within 10 seconds the change will be disregarded and the previously accepted guide point will be restored.

Web Position Indicators

Horizontal bar graph indicators (see Fig. 25) are available on the operator interface to indicate the position of the web as seen by the sensor. Both the edge position as well as the contrast position are indicated.

Depending on the position and orientation of the sensor the bar graphs may increase:

- from left to right for a sensor located on the right side of the web edge
- from right to left for a sensor that is located on the left side of the web edge.

The top web position indicator displays the right edge/contrast position of the web and the bottom web position indicator indicates the left edge/contrast position of the web. When two sensors (one left and one right) are connected or if a wide sensor is connected the edge position indicator may indicate both the left and the right edge of the web.




Fig. 25: SCU5 Operator Interface

Web Detected Indicator

A small square indicator on the bottom left part of the screen (see Fig. 25) indicates the presence and absence of the web as seen by the sensor.

- Whenever the sensor sees a web or a web edge, the indicator turns green.
- When the web is outside the sensing window the green indication goes off.

This web detect indicator can be used for troubleshooting purposes. If this indicator turns off intermittently while a web is in front of the sensor it may indicate that the sensor is finding it difficult to accurately sense the web. This indicates a low contrast condition for the sensor. Such a condition may occur for optical grade clear webs with low scattering in the infrared spectrum.

Sensor Position Indicator

The position of the sensor is indicated by two square indicators on the display (see Fig. 25) that are located downstream of the web guide picture.

- The indicator turns green to display the position and orientation of the sensor with respect to the guide and the web edge.
- If no sensor is attached to the web guiding system then both the indicators will turn gray.

- If two sensors (one right and one left) are attached to the web guiding system or if a wide sensor with center guiding option is used, both indicators will turn green.
- It is important to ensure that the sensor position indicator accurately indicates the actual position of the sensor with respect to the guide.
- The operator can find the correct position of the sensor by pressing the find sensor button that automatically detects the position of the sensor.

Find Sensor Button

The Find Sensor Button (see Fig. 25) can be used to automatically detect the position and orientation of the sensor with respect to the web guide and the web edge. Once the button is pressed the button will change state (as shown in Fig. 26) until the web edge is found.

- This button should be used whenever the sensor position is changed or when the edge orientation is changed.
- When the edge orientation changes, the bar graph will also change orientation.
- Find sensor button is activated only when the web guiding system is in manual mode.



Fig. 26: Find sensor operation

Communication Indicator

A round indicator at the left bottom of the operator interface (see Fig. 23) indicates the communication between the electronic controller board and the operator interface.

- This indicator is used for troubleshooting purpose.
- During normal operation this indicator will switch between red and green at a frequency of ~2 Hz.

Advanced Settings

The SCU5 retrofit kit is a truly plug and play system without any need for setup or calibration. However, it may be necessary to adjust a few parameters in rare occasions based on the processing conditions. The advanced setting screen (see Fig. 28) will allow the user to adjust four parameters: edge/contrast sensing, motor speed, minimum contrast and web width (not available in all versions).

Password Screen

To prevent any unintended changes to the setting some of the controllers will have password protected advanced settings screen. Different passwords to access different screens are available based on the controller purchased. The password screen that is presented would look similar to the screen shown in Fig. 27. The four digit numerical password can be entered using the touchpad and can be authenticated by

pressing “Enter.” Another button would appear with the password authentication, which when pressed would provide access to the advanced settings screen.




Fig. 27: Password screen




Fig. 28: Advanced settings screen

Motor Speed

In rare occasions when the web guide reaction speed needs to be reduced the speed slider can be used to vary the speed. The default setting corresponds to 99% of the maximum speed and the speed can be reduced all the way up to 0%. The speed reduction may be necessary while handling delicate material such as thin foils.

WARNING: When the speed is set to 0% the web guide will not respond in the automatic mode.

Minimum Contrast

When contrast web position sensing method is chosen the contrast slider can be used to set the minimum contrast that the web position sensor can detect. The default setting is 50 with a minimum of 0 and a maximum of 100. This relative scale adjusts the contrast sensitivity of the sensor output.

WARNING: The minimum contrast setting will have no effect when edge position sensing method is used.

WARNING: A very low contrast setting will make the sensor to be extremely sensitive to minute contrast difference.

Edge/Contrast Web Position Sensing



Edge sensing



Contrast sensing

Depending on the type of sensor (infrared or white light or ultraviolet) the web guide can operate in either edge sensing mode or contrast sensing mode. The default configuration is edge sensing with infrared light source.

In edge sensing mode the sensor will look for the web edge scanning from the outside to the inside of the sensor. For a left sensor the scan goes from left to right, while for a right sensor the scan goes from right to left (see Fig. 29).




Fig. 29: Left sensor orientation (left) and right sensor orientation (right)

Contrast sensing mode is intended to be used only with white light sensor. This sensing mode can be used to detect a line or a contrast in the web. In contrast sensing mode the position, of the first contrast change in the web, as the sensor scans from inside to outside is detected. An additional setting to optimize the sensor performance (contrast adjustment) is available for advanced users through the advanced setting screen.

WARNING: Do not use contrast sensing method with an infrared sensor unless there is a specific need that has been already identified and tested.

WARNING: The Edge/Contrast sensing icon is visible, and can be used, only when the web guiding system is in manual mode.

WARNING: Both edge and contrast sensing method may work with white light. Additionally optical clear material may be difficult to sense with a white light option.




Fig. 30: Advanced Settings Screen (with width output options)

Web Width

Web width changes can be monitored in real-time for quality control purposes using the SCU5 controller. The web width selection slider (only available in certain models) can be used to set the type of width output from the web guiding system. The output is an analog voltage based on the choice of width measurement or width monitoring. This setting is valid only when two sensors, one left and one right, or a wide sensor is used.

Analog Output

When the width output is set to be analog, the SCU5 controller sends an analog output ranging between 0 to 10 Volts based on the percentage of the sensor(s) covered by the web. For example, with a wide sensor if the web covers 60% of the sensor window 6 Volts is output. If two sensors are used, one left and one right, then the output will be the total percentage of the two sensors covered by the web on either side.

Digital Output

The digital output option can be used for event based web monitoring. When this option is selected additional settings are available to the user as shown in Fig. 30.

WARNING: This option is not available on all the web guiding systems.




Fig. 31: Digital width output settings.

A lower (-ve limit) and an upper (+ve limit) web width tolerance can be set to trigger outputs based on web width. By default the lower and upper limits are set to zero. The resolution of the tolerances is in millimeters. By using the up and down buttons the lower limit and the upper limit can be changed. Any change in the limits must be accepted by pressing the “Accept Limits” button that becomes visible when the limits are changed (see Fig. 32). The nominal web width is recorded at the instant when the “Accept Limits” button is pressed. As soon as the “Accept Limits” button is pressed the button disappears indicating the limit acceptance as shown in Fig. 33.




Fig. 32: Accept Limits button is visible after a limit change.

When the web width increases above the positive limit a positive high signal (+10V) is sent out by the SCU5 controller. Similarly when the web width decreases below the negative limit a negative low signal (-10V) is sent out. When the web width is within the positive and negative width limits 0V is output.




Fig. 33: User interface after the pressing Accept Limits button.

WARNING: If only one edge sensor is present then the output from the web guiding system, irrespective of the web width setting, will be an analog voltage between 0 to 10 Volts proportional to the web position (the percentage of the sensor covered by the web).

WARNING: Whenever a different web material with different nominal width is used the nominal width and the limits must be reset.

Remote Control and Monitoring

A set of input and output registers are available to monitor and control the web guiding system remotely.

Output registers

The output registers from the sensor provide information from the sensor. The data include status/fault information, sensor position information and sensor measurement quality information. The data from the sensor is organized in the following registers:

Register #	bit 15	bit 14	bit 13	bit 12	bit 11	bit 10	bit 9	bit 8	bit 7	bit 6	bit 5	bit 4	bit 3	bit 2	bit 1	bit 0
0	Sensor 1 status/fault register															
1	Sensor 2 status/fault register															
2	Sensor 1 position output															
3	Sensor 2 position output															
4	Sensor 1 quality factor								Sensor 2 quality factor							
5	Web guide status/fault register															
6	Guide point percentage								Diagnostic index							
7	Motor speed percentage															

Sensor status and fault registers

The sensor status/fault register is organized as follow. The eight least significant bits correspond to fault information while the eight most significant bits correspond to status information.

Bit #	Value	Label	Description
0	0/1	No sensor	0: if a sensor is present 1: if no sensor is connected
1	0/1	Low contrast	0: if measurement contrast is high 1: if measurement contrast is low
2	0/1	No web	0: if web is detected by the sensor 1: if the sensor cannot detect a web

3	0/1	Wrong orientation	0: if sensor orientation is correct 1: if the sensor see an edge in the opposite orientation to which it is set up
4	NA		Reserved for future use
5	0/1	Flutter	0: if no flutter is detected 1: if the sensor detects flutter or out of plane movement in the web
6-7	NA		Reserved for future use
8	0/1	Left Sensor	0: if the sensor not set as a left sensor 1: if the sensor is set as a left sensor
9	0/1	Right Sensor	0: if the sensor not set as a right sensor 1: if the sensor is set as a right sensor
10-12	0-4	Number of pixels	The number of pixels in the sensor 0: 256 1: 768 2: 1774
13-15	0/2	Sensing mode	0: edge sensing mode 2: contrast position sensing mode

NOTE: If both the left sensor and the right sensor bits are set then the configuration corresponds to center sensor mode. For wide sensors (such as ARIS WPS 221) a single sensor may be used to measure the position of the two edges of the web, if the width of the web is smaller than the sensing window of the sensor.

Sensor position output register

The sensor position output register provides the absolute measurement in pixels. The output ranges from 0 to number of pixels in the sensor, and depending on the sensor orientation the output corresponds to edge position or contrast position. In order to convert the position into a physical unit, such as millimeters or

inches, the sensor resolution and the total pixel number of the sensor head are necessary. The following table provides a summary of the resolution and pixel count information for the different ARIS WPS models.

Model	Resolution	Total Pixel Count
ARIS WPS 16	0.0635 mm or 0.0025 in	256
ARIS WPS 48	0.0635 mm or 0.0025 in	768
ARIS WPS 221	0.125 mm or 0.005 in	1774

In either sensor orientation (left or right) the measured position increases as the web moves from left to right. **NOTE:** The output when the web completely covers the sensor or when the web is completely outside the sensor window would be different based on the sensor orientation.

Sensor Orientation	Completely open	Fully covered
Left sensor orientation	Number of pixels	0
Right sensor orientation	0	Number of pixels

If no sensor is present then the value in the sensor position output register is meaningless.

With a wide sensor (such as ARIS WPS 221) center guiding with one sensor is possible if the width of the web is smaller than the sensing window of the sensor. When a single sensor acts as center sensor both the left and the right edge will be output via the industrial ethernet option. Irrespective of the sensor number the output for the left edge of the web is always available at the Sensor 1 position output register and the right edge of the web is available at the Sensor 2 position output register.

NOTE: If two sensors are connected and both are in center sensor mode the Sensor 1 position output and Sensor 2 position output will always correspond to the left and the right edge of the web seen by Sensor 1. Likewise for guiding purposes, the web guide will guide to the center of the web as measured by Sensor 1. The Sensor 2 output will be disregarded.

Quality factor registers

The quality of the sensor measurement from the two sensors are provided in register 4. Higher number corresponds to good quality measurement while a low number indicates lower quality. The value of the quality factor ranges from 0 to 256. The eight most significant bits of register 4 corresponds to the 8-bits quality factor from sensor 1 while the eight least significant bits corresponds to the quality factor of sensor 2.

Web guide status and fault registers

Bit #	Value	Label	Description
0	0/1	No operator interface	0: if no operator interface is detected 1: if an operator interface is detected

1	0/1	No motor driver	0: if no motor driver is detected 1: if a motor driver is detected
2	0/1	Motor fault detected	0: if motor motor function is normal 1: if a motor fault is detected
3	0/1	Disturbance detected	0:if no disturbance is detected 1: if a disturbance is detected
4	0/1	Traction issue detected	0: if no traction issue is detected 1: if a traction issue is detected
5	0/1	Upstream misalignment	0: if no upstream misalignment is detected 1: if an upstream misalignment is detected
6	0/1	Guide extreme position	0: if the web guide is within the normal position 1: if the web guide is in an extreme position
7	0/1	High frequency disturbance detected	0: if a high frequency disturbance is detected 1: if no high frequency disturbances are detected
8	0/1	Manual/Auto	0: if the web guide is in manual mode 1: if the web guide is in automatic mode
9	0/1	Jog Left operation	0:if the web guide is not jogging left 1: if the web guide is jogging left
10	0/1	Jog Right operation	0: if the web guide is not jogging right 1: if the web guide is jogging right
11	0/1	Servo Centering operation	0: if the web guide is not servo centering 1 if the web guide is servo centering

12	0/1	Good guiding performance	0: if the guiding performance is not good 1: if the guiding performance is good
13-15	NA		Reserved for future use

Guide point percentage

The guide point for the web guide is provided in this register. The value of the guide point range between 0 and 100, representing the guide point as a percentage of the sensor range. A value of 50 indicates that the guide point is at the middle of the sensing window while a value of 25 means the guide point is at the 25% of the sensor window (left of the middle) while a value of 75 means the guide point is at 75% of the sensor window (right of the middle). The eight most significant bits of register 5 provide the guide point percentage output.

Diagnostic index

The diagnostic index output is only available with web guiding that include the KOIOS diagnostic index. The value ranges between 0 and 100. For more details please refer to the KOIOS diagnostics product manual. The eight least significant bits of register 5 provide the diagnostic index output.

Motor speed percentage

The motor positioning speed as a percentage of maximum speed is output in register 7. The value ranges between 0 and 100.

Sensor input registers

Sensor input registers are control registers that are used to control/configure the parameters of each sensor. One 16-bit command register for each sensor is available for an external device to set the sensor parameters. The input registers are mapped as shown below:

Register #	bit 15	bit 14	bit 13	bit 12	bit 11	bit 10	bit 9	bit 8	bit 7	bit 6	bit 5	bit 4	bit 3	bit 2	bit 1	bit 0
0	Sensor 1 command register															
1	Sensor 2 command register															
2	Guide command register															
3	Guide point offset register															
4	Motor speed percentage register															

Sensor command register

Bit #	Value	Label	Description
0-1	0/2	Sensor orientation	0: set sensor orientation to be right sensor 2: set sensor orientation to be left sensor Note: Changing this value will take effect only if bit 5 is set to 1. The auto switch mode needs to be disabled to take control of the sensor orientation through this register.
2-3	0/1		Reserved for future use
4	0/1	Sensing mode	0: set the sensing mode to be edge mode 1: set the sensing mode to be contrast mode
5	0/1	Disable auto switch off	0: Automatic switch is enabled 1: Automatic switch is disabled Note: This bit needs to be set in order to force the sensor orientation externally. If this bit is cleared to zero the sensor will maintain the previous orientation until the sensor automatically detects the sensor orientation when (1) find sensor is enabled or (2) when a new sensor is plugged into the sensor port.
6	0/1	Find sensor	0: Disable find sensor operation 1: Enable find sensor operation by resetting the orientation and allowing the sensor to detect the web orientation. Note: This bit is momentary when set to one. Every time the find sensor operation needs to be enabled the bit needs to be cleared to zero before setting it to one.
7	0/1	Disable analog output	0: Enables the analog output for the sensor 1: Disables the analog output for the sensor
8-15	0-255	Minimum contrast	Minimum contrast: Minimum contrast required to accept an edge in contrast mode Default value is 50.

Web guide command register

Bit #	Value	Label	Description
0-7	NA		Reserved for future use
8	0/1	Remote control	0: if cleared to zero, the local operator interface have control over the web guide 1: if set to one, the remote ethernet controller has control over the web guide. The interface icons to control the web guide on the local operator interface will be disabled. Information for monitoring purposes will be displayed on the screen.

9	0/1	Manual/Auto mode	<p>0: if cleared to zero, the web guide will be placed in the manual mode</p> <p>1: if set to one, the web guide will be placed in the automatic mode</p>
10	0/1	Jog Left or decrease guidepoint	<p>This bit performs two functions based on bit 9.</p> <p>If bit 9 is cleared:</p> <ul style="list-style-type: none"> ● 0: Stop Jog Left operation ● 1: Start Jog Left operation <p>Note that this register is a write only register and will not change state if the web guide reaches the extreme position.</p> <p>If bit 9 is set:</p> <ul style="list-style-type: none"> ● 0: will clear the register and has no effect ● 1: will decrease the guide point by 0.254 mm or 1/100th of an inch from the current value. <p>Note that this value on this register is momentary. Before decreasing the guidepoint the bit needs to be cleared before setting it to one. Note that the guide point cannot at the extremes of the sensing window and will automatically truncated if the extreme limit is reached. The extreme limit depends on the sensor resolution and sensor width.</p>
11	0/1	Jog Right or increase guidepoint	<p>This bit performs two functions based on bit 9.</p> <p>If bit 9 is cleared:</p> <ul style="list-style-type: none"> ● 0: Stop Jog Right operation ● 1: Start Jog Right operation <p>Note that this register is a write only register and will not change state if the web guide reaches the extreme position.</p> <p>If bit 9 is set:</p> <ul style="list-style-type: none"> ● 0: will clear the register and has no effect ● 1: will increase the guide point by 0.254 mm or 1/100th of an inch from the current value. <p>Note that this value on this register is momentary. Before increasing the guidepoint the bit needs to be cleared before setting it to one. Note that the guide point cannot at the extremes of the sensing window and will automatically truncated if the extreme limit is reached. The extreme limit is set such that at least ± 3.175 mm is available on either side of the adjusted guide point.</p>
12	0/1	Servo Center operation or set guide point	<p>This bit performs two functions based on bit 9.</p> <p>If bit 9 is cleared:</p> <ul style="list-style-type: none"> ● 0: No effect ● 1: Start Servo Center operation <p>Note that this register is a write only register and will not change state if the web guide reaches the center position. Note that this value on this register is momentary. Before a servo center operation the bit needs to be cleared to zero before setting it to one.</p> <p>If bit 9 is set:</p> <ul style="list-style-type: none"> ● 0: will clear the register and has no effect

			<ul style="list-style-type: none"> 1: will set the guide point to be at 50% of the sensing window. <p>Note that this value on this register is momentary. Before decreasing the guidepoint the bit needs to be cleared before setting it to one. The extreme limit is set such that at least ±3.175 mm is available on either side of the adjusted guide point.</p>
13	0/1	Enable arbitrary gross guide point adjustment	<p>This bit allows arbitrary gross adjustment of the guide point offset through the industrial ethernet interface.</p> <p>0: if cleared to zero, gross guide point adjustment is disabled</p> <p>1: if set to one, the remote ethernet controller can make arbitrary gross adjustment to the guide point by writing a 16-bit signed integer to the guide point register.</p>
14-15	NA		Reserved for future

WARNING: All the remote control operations may cause the web guide to move without operator intervention. This process may cause process upsets. Caution must be exercised when performing these function and should be done by those who completely understand the consequence of this change.

WARNING: The web guide is an automatic control device that may stop and start at any time without notice, especially when controlled remotely. Hence standard safeguards must be in place to prevent any kind of injury.

WARNING: The remote control options provides significant access and control of the web guide and the sensor. A combination of the settings may create conditions that might not be ideal for web guiding. Hence only the personnel familiar with the web guide operation should program the remote control interface. Contact Roll-2-Roll Technologies' technical support team for any question or assistance.

Guide point offset register

If the 13th bit of the web guide command register is set, then arbitrary guide point adjustment can be made by writing a 16-bit signed integer value to the guide point offset register. The offset value is the distance from the desired guide point location to the middle of the sensor window. A positive offset value will result in a guide point location towards the right half of the sensor window while a negative offset will result in a guide point location towards the left half of the sensor window. The guide point offset in mm = 0.0635*(the 16-bit guide point offset register).

Motor speed register

The positioning speed of the actuator can be changed by setting the 7th bit of the register to 1 and writing a value between 0 and 100 in the 7 least significant bits. If the 7th bit is low then the value written in the register is ignored. Any value in the 15th to 8th bit within the register is also ignored.

Communication Module

Off-shelf industrial ethernet modules from [HMS industrial](#), are used in the ARIS SCU C(E)/MC(E) to provide ethernet connectivity. A 4-pin D-coded M12 socket connect is provided for ethernet connection. Standard network cables can be used to connect the ARIS SCU C(E)/MC(E) to an ethernet network using RJ45 plug.

IP Address


The ARIS SCU C(E)/MC(E) is configured to automatically acquire an IP address from a DHCP router or a server. As soon as the controller is connected to a network, an IP address is automatically assigned to the device. Before starting the configuration procedure find the IP address of the controller on the network.

Finding the IP Address


Once the controller is powered ON, the controller will automatically connect to the network. The controller is configured to get the IP address automatically from a DHCP server. Hence the controller should be connected to a network where dynamic IP addresses are issued by a network device such as a router.

A network port scan utility can be used to find the controller. Alternatively the [IPConfig](#) utility available in the software section of the [HMS Industrial website](#) can be used to scan for the device. The actual device used is **Anybus-IC EtherNet/IP ORDER CODE: AB6003**.

Once the utility is installed the program can be run to find the AnyBus IC module on the ARIS SCU C(E)/MC(E). The following shows the opening screen of the IPconfig utility.




By pressing the scan button all the devices on the network from HMS Industrial network can be found. For example, the utility would find the device and list it as shown below.




Information such as IP address, DHCP state, Type of module and the MAC address is displayed.


Setting a static IP address for the controller

Double clicking on the desired device listed in the IPConfig window would bring a screen to configure the Static/Dynamic IP address setting as shown below. By selecting the DHCP setting to be off, static IP address can be configured for the device.





By clicking on the “Set” the static IP address can be set. Once the static IP address is set the IPconfig utility will refresh to show the new configuration. The DHCP setting will be set to “OFF” state and the new IP address will be assigned to the device as shown below.



COMMISSIONING

A properly installed web guide requires correct threading of the web over the guide rollers and initial positioning of the sensor. Once the material is threaded over the guide rollers and the sensor has been properly positioned, all that the operator has to do is to press the automatic operation icon on the operator interface.

The following section describes the steps and conditions required for automatic operation of the web guide.

1. Power ON the system
2. Automatic/Manual operation set to “Manual” (Automatic/Manual icon pressed to red)
3. Jog the guide to left extreme and then to right extreme to correct for any transportation related guide roller assembly movements.
4. Press the Servo-Center button to center the guide rollers.
5. Thread the material over the rollers depending on the web path configuration. The material wrapped over the rollers must be at a 90 degree angle both at the entry and exit of the guide rollers.
6. Verify that the material is aligned in the desired position with respect to the upstream and downstream position of the web. Place web under normal operation tension.
7. Adjust sensor position on the desired edge of the web. Then manually position the sensor so that the edge of the web is at the middle of the sensing window. This can be done by observing the web edge position indicator on the display. When the bar is in the middle position then the web edge is in the middle of the sensing window.
8. If the sensor position indicator and the actual position of the sensor are different then press the “Find Sensor” button on the operator interface so that the guiding system automatically find the correct orientation of the edge sensor. In order for this function to work the web edge needs to be in the middle of the sensing window.
9. Secure the sensor position on the sensor rail.
10. Press the Automatic/Manual operation icon to “Automatic” (Automatic/Manual icon pressed to green).
11. The guide will automatically adjust the position of the web material to guide it to the correct position.

General Maintenance

The Retrofit Kit is virtually maintenance free. However, the sensor lid should be cleaned to remove any dust particles that might accumulate on the surface.

- You may use any lens cleaning solutions available in the market.
- Do not use petroleum based products as these can damage the sensor cover and affect its performance.

This cleaning can be done as part of a weekly maintenance schedule or as required by usage or environmental conditions.

TROUBLESHOOTING

Problem	Probable Cause	Action
<p>Sensor indicator does not light up and the sensor does not find the web.</p>	<p>Background or faulty sensor cable or connection.</p>	<ul style="list-style-type: none"> * Ensure that the background in the field of view of the sensor is dark. Any bright surfaces may reduce the contrast levels and can prevent automatic find sensor operations. * Ensure that the sensor cable is properly connected. Disconnect the cable and reconnect it and use the find sensor button procedure. * If that does not fix the problem try a different sensor head. * If that does not fix the problem please call support.
<p>The touch screen does not work and the communication indicator is not blinking.</p>	<p>Communication between the electronic hardware and the operator interface is lost.</p>	<ul style="list-style-type: none"> * Power cycle the web guiding system to see if the communication is reestablished. * If that does not fix the problem, please call support.
<p>The web guide is not moving in automatic mode.</p>	<p>Faulty cable or connection. or Software soft stop reached.</p>	<ul style="list-style-type: none"> * Check the sensor cables and connection to ensure that the sensor sees the web. * If the sensor works properly, then try to manually jog the web guide away from the center position. The web guide will stop jogging when the software soft stop is reached. While jogging, the actuator may produce a noise because of the hard stop. It is normal. Once the software stops jogging, push the automatic button again. * If that does not fix the problem, please call support.

APPLICABLE MODELS

Sensor

Model Number	Description	Part Number
ARIS WPS 16-IR	Light source: Infrared; Width: 16 mm	3-000011
ARIS WPS 48-IR	Light source: Infrared; Width: 48 mm	3-000012
ARIS WPS 48-WL	Light source: White light; Width: 48 mm	3-000022
ARIS WPS 48-UV	Light source: Ultraviolet; Width: 48 mm	3-000032
ARIS WPS 221-IR	Light source: Infrared; Width: 16 mm	3-000014

Control Unit

Model Number	Description	Part Number
SCU5 MD	Basic controller + integrated touch screen display	4-100121
SCU5 MC(E)	Basic controller + industrial ethernet (Ethernet/IP)	4-100112
SCU5 MC(P)	Basic controller + industrial ethernet (PROFINET)	4-101112
SCU5 MC(E)D	Basic controller +Ethernet/IP + integrated touchscreen display	4-100111
SCU5 MC(P)D	Basic controller +PROFINET + integrated touchscreen display	4-101111

TECHNICAL SUPPORT AND SERVICE

Contact information

Roll-2-Roll Technologies LLC is dedicated to providing exceptional service and support to its customers. Please feel free to contact us for any technical support, installation support and service requirements.

Roll-2-Roll Technologies LLC
1110 S Innovation Way Dr
Stillwater, OK 74074
Website: <https://www.r2r-tech.com>

Technical Support Phone: +1 (888) 290-3215 - ext 3
General Support Phone: +1 (888) 290-3125 - ext 1

Technical Support Email: engineering@r2r-tech.com
General Support Email: support@r2r-tech.com

Return shipping instructions

Please contact us to obtain a return merchandise authorization (RMA) number before returning the product to us. If returning the product, please follow the instructions on the RMA form for quick and efficient service.

REVISION HISTORY

Document Revision

Version	Date	Changes
1.0	Jan 2017	Initial Release Version
2.0	Sep 2017	Comprehensive revision with the SCU5 controller.

Hardware Revision

Version	Date	Description
SCU V2	Dec 2014	Initial version with 12 VDC input
SCU V3	Jun 2015	Expanded version with 24 VDC input
SCU V4 Rev B	Oct 2015	Two sensor option, WDT, RTCC
SCU V4 Rev C	Mar 2016	Analog Output
SCU V4 Rev D	July 2016	Industrial ethernet option
SCU5	May 2017	Updated hardware with smaller form factor

Firmware Revision

Version	Date	Description
1.0	Jan 2015	Initial version, single sensor
1.1	Aug 2015	Firmware update for SCU V3, automatic sensor state detection
1.2	Nov 2015	Firmware update for SCU V4 Rev B. Modified sensor algorithm to increase precision and accuracy.
1.3	Dec 2015	Two sensor option with automatic pixel detection
1.4	Mar 2016	Background suppression algorithm
1.5	Apr 2016	Analog output
2.1a	Aug 2016	Firmware update for SUC V4 Rev D
2.2b	Dec 2016	Ethernet/IP implicit messaging, edge detection algorithm updates
2.4a	Jun 2017	Changes to guide point adjustment



Roll-2-Roll Technologies LLC
1110 S Innovation Way Dr
Stillwater, OK 74074
www.r2r-tech.com
info@r2r-tech.com
+1-(888)-290-3215