

SCU5: Controller

Product and User Manual

Firmware Version 3.4

Copyright Information

All of the information herein is the exclusive proprietary property of Roll-2-Roll Technologies LLC, and is disclosed with the understanding that it will be retained in confidence and will neither be duplicated or copied in whole or in part nor be used for any purpose other than for which it is disclosed.

Information in this document is believed to be reliable and accurate. However no responsibility is assumed as a result of its use nor for any inaccuracies, infringement of patent or other rights of third parties resulting from its use.

The information in this document is subject to change without any notice.

CONTENTS

INTRODUCTION	6
Web Guiding Application	6
Web Position Sensor	7
Web Guide Controller	7
Guide Mechanism	7
Measurement and Sensing Application	7
Sensor and Web Guide Controller Specification	7
Controller Options	8
Physical Dimensions of SCU5	9
Power Input	10
Switchcraft DC Connector	10
Industrial DIN Rail Power Supply	10
Grounding	10
Sensor Interface	10
Motor Communication	11
Analog Output	12
Industrial Ethernet Interface	12
Opto-Isolated Output	12
Instructions for Use	14
Proper Use	14
Improper Use	14
Static Discharges and Grounding	14
OPERATION AND OPERATOR INTERFACE	15
Main Operator Interface Screen	15
Heartbeat Indicator	15
Web Detected Indicator	16
Web Position Indicator	16
Sensor Position Indicator	17
Find Sensor Button	17
Automatic/Manual Icon	17
Servo Center Icon	18
Jog-left/Jog-right Icon	19
Guide Point	20
Guide Point Indicator	20
Guide Point Offset	20
Guide Point Adjustment	20
Fine Guide Point Adjustment	20

Gross Guide Point Adjustment	21
Reset Guide Point	21
Advanced Settings Menu	22
Operator Settings Screen	23
Operator Sensor Screen	23
Sensor Mode	23
Thresholding Mode	23
Sensor Selection	25
Minimum Contrast Gauge	25
Brightness Gauge	25
Brightness Control	25
Live Processed Image Preview	26
Selected Feature	26
Feature Navigation	26
Teaching	26
Contrast Mode	26
Right edge of a color	27
Edge created by two colors	28
Color of a line	28
Left Edge of a color	29
Operator Width Screen	30
Nominal Width	30
Upper Limit	31
Lower Limit	31
Measured Width	31
One Sensor	31
Two Sensors	31
Teaching	32
Output Type	32
Absolute	32
Error	33
Power User Screen	33
Actuator Setting	33
Stroke	34
Pitch	34
Motor Polarity	35
Servo Center Polarity	35
Speed	35
Acceleration	35
Sensor Setting	35
Automatic Brightness Control	36

Brightness Value	36
Enable/Disable Sensor	36
Sensor Position/Orientation Setting	37
Controller Setting	37
Gain	37
Deadband	38
Lock on Lost Edge	38
Servo Center	38
Limit Switches	39
Analog Output Setting	39
Output range selection	39
Analog mode	40
Analog setup	40
Password Setting	40
Communication Setting	41
Ethernet	41
DHCP	41
FTP	42
IP	42
Subnet Mask and Gateway	42
MAC address	43
Module Type	43
Network Status	43
REMOTE CONTROL AND MONITORING	44
Output registers	44
Sensor status and fault registers	44
Sensor position output register	46
Quality factor registers	46
Web guide status and fault registers	46
Guide point percentage	48
Actuator speed percentage	48
Actuator acceleration percentage	48
Controller Input Registers	48
Sensor command register	48
Web guide command register	49
Guide point offset register	51
Actuator speed register	51
Actuator acceleration register	51
Communication Module	51
IP Address	51
Finding the IP Address	52

Setting a static IP address for the controller	53
Adding an EtherNet/IP module in Rockwell/AB Ecosystem	54
Configuring the module parameters	55
Configuring communication options	55
Importing Add-On-Instruction	56
Using SCU5 C(E) Add-On Instruction	58
Sensor variables	59
COMMISSIONING	61
Sensing and Measurement Application	61
Web Guiding Application	61
Edge Guiding	61
Center Guiding Application	62
Standard Operating Procedure	62
General Maintenance	62
TECHNICAL SUPPORT AND SERVICE	63
Contact information	63
Return shipping instructions	63
REVISION HISTORY	64
Document Revision	64
Hardware Revision	65
Firmware Revision	66

INTRODUCTION

This product manual provides information about installation, use and maintenance of SCU5 controller. The controller includes an operator interface that is used for both measurement and control applications within converting lines. For installation of the sensor and web guide please refer to the respective product manuals.

The controller is designed for use in indoor industrial and laboratory equipment that process materials in web form as they move through a converting or raw material manufacturing process.

The controller can be used in closed loop control applications such as web guiding applications for edge, contrast and center guiding. The controller can also be used for other standalone sensing applications such as width measurement, thread counting, mark detection, contrast position measurement, gap detection and the like.

Web Guiding Application

A web guiding system is a fully automatic mechatronic system used to accurately align/steer web materials within roll-to-roll machines. The web guide is used at critical locations where accurate alignment of web is necessary. Typical locations include at the unwind section, before process sections, such as before printing, coating, laminating, slitting, and rewind section. Accurate web guiding will improve productivity by enabling high speed transport and manufacturing.

There are three main components to a web guiding system:

- 1. Web position sensor
- 2. Web Guide Controller
- 3. Guide mechanism



Fig. 1: Components of a web guiding system

Web Position Sensor

The web position sensor provides the vision for the control system. The sensor captures the image of the web position (edge or a contrasting feature on the web) and sends that information to the controller for further processing.

Web Guide Controller

The controller is the brain for the control system. Based on the image captured by the sensor controller processes the image and determines the corrective action necessary to accurately align the web material. The web guide controller encloses the electronic hardware for the sensor processing, operator interface and the control algorithm for the web guide/actuator.

Guide Mechanism

The web guide mechanism is the muscle for the control system. The guide mechanism actuated by a motor physically steers the web to the required position based on the command from the controller.

Measurement and Sensing Application

The controller along with an appropriate sensor head can be used for standalone sensing applications such as edge detection, contrast position detection, width measurement, web centerline position measurement, thread counting, gap detection, etc. The sensor and the controller perform the same functions, however further processing is carried out by the controller to provide higher level measurement information.

Sensor and Web Guide Controller Specification

The general specifications of the SCU5 controller are listed below. Depending on the application one of more of the output options would be available.

Operator Interface	Optional color touchscreen	Output (Voltage)	± 10 V or 0 to 10 V
Languages	Language independent	Output (Current)	0 to 20 mA or 0 to 10 mA
Motor Driver	Microstepping or servo drive	Connectivity	EtherNet/IP, PROFINET
Motor	Servo or Linear hybrid stepper	Input Supply	24 V DC
Controller Frequency	50 to 200 Hz	Current	5 A

The most basic controller is the SCU5 D which has the operator interface integrated within the controller. The controller is used for standalone measurement and sensing applications. Analog output of the sensor measurement is provided so that the controller can be connected to legacy systems (legacy web guide controllers, servo valves, pneumatic valves, etc.) for closed loop control. The analog output can also be connected to a PLC for measurement monitoring application. Advanced measurement and sensing applications can utilize either the EtherNet/IP or PROFINET industrial Ethernet connectivity option.

For a web guide controller, the analog output option is replaced with an RS485 communication option to drive a web guide actuator driver manufactured by Roll-2-Roll Technologies LLC.

Controller Options

Options	SCU5 D	SCU5 C⁴(X)D	SCU5 MD	SCU5 MC⁴(X)D	
Input	24 VDC	24 VDC	24 VDC	24 VDC	
Application	Sensing	Sensing	Web Guiding	Web Guiding	
Analog output	YES	YES	NO	NO	
Voltage output options	± 10 V ²	± 10 V ²	NONE	NONE	
Current output	0 to 20 mA ³	0 to 20 mA ³	NONE	NONE	
Motor Controller			YES	YES	
Current Consumption	< 2.5 Amps	< 3 Amps	< 5 Amps	< 5 Amps	
Controller Frequency	50 - 200 Hz	50 - 200 Hz	50 Hz	50 Hz	
Industrial Ethernet		YES		YES	
Web browser dashboard		YES		YES	
Remote Control		YES		YES	
Diagnostics/Fault Info		YES		YES	
Process two sensors	YES	YES	YES	YES	
GO/NO GO	YES ¹	NO	YES ¹	NO	
Standalone System	YES	YES⁵	YES	YES⁵	

Following table shows the capabilities of the different controller option

¹ Two digital 24 V NPN GO/NO GO output are available upon request. This is not a standard.

² can be programmed to be ± 10 V or 0 to 10 V or ± 5 V or 0 to 5 V based on application requirement

³ can be programmed to be 0 to 20 mA or 4 to 24 mA or 0 to 10 mA based on application requirements.

⁴ the industrial ethernet has two options C(E) for EtherNet/IP and C(P) for PROFINET

⁵ can be made standalone when not connected to a remote controller (PLC) or when set by remote controller (PLC)

Physical Dimensions of SCU5



Fig. 2: SCU5 M Controller Physical Dimensions (All dimensions are in mm); Subject to change without notice.

The SCU5 M controller has the following ports for connections to the sensor, motor driver and other devices.



Fig. 3: SCU5 MD Connector Ports

Power Input

The SCU5 M operates under 24 VDC (± 5%) power with a maximum current requirement of 5 Amps. The power is supplied through a Switchcraft DC power connector.

WARNING: Supplying more than 24 VDC would damage the controller permanently.

WARNING: A reverse polarity connection may also damage the controller permanently.

Switchcraft DC Connector

Sealed <u>Switchcraft L712AS</u> power jack port option is available on the SCU5. A mating <u>Switchcraft 761KS12</u> plug connector or a pre-assembled <u>Switchcraft CARA761KS07984</u> or a pre-assembled <u>Switchcraft</u> <u>CA761KS07984</u> can be used to supply power. For the plug connector the 24 VDC power should be supplied to the tip/center pin and electronic ground on the sleeve pin. For the pre made cable assembly from Roll-2-Roll the 24 VDC should be connected to the red cable and the electronic ground connected to the black cable.



Industrial DIN Rail Power Supply

Industrial DIN rail mountable power supply such as <u>Mean Well SDR-75-24</u> can be used to supply 24VDC power. This is an available purchase option.

Grounding

For safety and for normal operation, the SCU5 M controller, the equipment to which the controller is installed must be properly grounded. The metal enclosure surface or the mounting screws may be used to properly ground the controller to the protective earth.

WARNING: Please use all possible options to safely earth ground the controller. Improper grounding may result in static buildup that can potentially result in malfunction of the controller.

Sensor Interface

Two sensor ports labeled Sensor 1 and Sensor 2 have industry standard 12-pin M12 connectors to connect the 12-pin connector on the sensor cable. Either sensor ports can be used to connect the sensor(s) and the controller will automatically recognize the connection.

WARNING: The connectors are keyed and please DO NOT force the connectors. Forcing the connector may damage the pins and eventually can damage the sensor and or the controller.

NOTE: If two sensors are connected and configured for edge mode, the controller will automatically configure the appropriate guiding method based on the orientation of the edges. If both the left and the right edge is seen by the sensor, the center guiding mode will be enabled. If both the sensors see the same edge of the web then an average of the sensor measurement will be used to guide the web.

NOTE: If two sensors are connected and configured for contrast mode, only the sensor that is selected will be used for guiding.

NOTE: The sensors can be enabled or disabled electronically within the controller even if they are physically connected with cables.

NOTE: If two sensors are connected and configured for edge mode, the analog output can be configured for left edge, right edge, centerline web position or web width.

NOTE: If two sensors are connected and configured for contrast mode, the analog output can be configured for left edge, right edge, centerline web position or web width.

WARNING: Only the sensors and cables provided by Roll-2-Roll Technologies LLC should be connected to the sensor ports. Third-party cables and sensors may damage the controller and will void the warranty. Please consult with the factory before adding any patch cords.

Motor Communication

The SCU5 controller with "M" suffix includes a 4-pin Male M8 connector to connect the controller to a motor driver (supplied by Roll-2-Roll Technologies LLC) used for web guiding applications. A pre-wired motor communication cable with the 4-pin M8 female connectors on both ends is used to connect the controller and the motor driver. The motor communication cable carries the power and the communication signals between the SCU5 M controller and the motor driver.

3×1	Pin	Color	Signal
4 2 2	1	Brown	+24 V
1 = BROWN	2	White	RS 485 B-
2 = WHITE 3 = BLUE	3	Blue	RS 485 A+
4 = BLACK	4	Black	GND

WARNING: Never connect or disconnect the motor communication cable while the SCU5 controller is powered or connected to a power supply. Always power down the SCU5 controller during the connection/disconnection of the motor communication cable.

WARNING: Only the cables provided by Roll-2-Roll Technologies LLC should be connected to the motor communication port. Third-party cables and sensors may damage the controller and will void the warranty.

Analog Output

The SCU5 controller without the motor suffix will include a 3-pin Male M8 connector for analog output. The pinouts for the connector are shown below.



The outputs can be chosen via the touchscreen interface to any of the following available output options:

Voltage	Current					
0 - 5 V, 0 - 10 V, ± 5 V, ± 10 V	4 - 20 mA, 0 - 20 mA, 0 - 24 mA					

WARNING: These pins are isolated outputs. Do not connect a power source to these pins. Some analog input cards on PLC might have a voltage source to power sensors. Please do not connect the voltage source to these pins. This might permanently damage the controller.

Industrial Ethernet Interface

An optional industrial ethernet connection is available on models with suffix C(E) or C(P). A 4-pin D-coded M12 socket connect is provided for ethernet connection. Standard network cables such as Phoenix Contact NBC-MSD/1,0-93E/R4AC SCO - 1407360 or VS-MSD-IP20-93E/5,0 - 1403500 can be used to connect the SCU5 M to an ethernet network using RJ45 plug.

4	Pin	Color	Signal
3-00-1	1	White/Orange	+TX
Contraction of the second s	2	White/Green	+RX
2	3	Orange	-TX
	4	Green	-RX

Opto-Isolated Output

For some applications two opto-isolated outputs are available from the SCU5 controller. These outputs are available on a 4-pin M12 female pin connector. A standard M12 4-pin A coded male connector or a pre-wired M12 cable can be used for the connection. The pin functions for the connector are shown in the table below.



The outputs can be used as NPN output by providing a VDD (5 – 24 VDC) and GND from a PLC and the signal through the two outputs OUT1 and OUT2. Custom programing can be done to provide a GO/NO GO type of output or a digital ON/OFF signal.



When the respective output signal is enabled then that signal would go low. And normally the signal would be high if wired as shown in the schematic on the left. Note that the outputs are normally closed. If wiring a relay, wire to the NC side of the circuit so that the appropriate output from the relay is provided to the device.

SAFETY INSTRUCTIONS

The SCU5 controller is an electronic device that operates on low voltage (24 V DC). However, it does present a few safety requirements that must be followed in order to assure safe and effective operation of the system.

Instructions for Use

The SCU5 controller must be properly transported, stored before being installed professionally. The controller should not be installed or commissioned for operation if any visible damage is observed. Only persons who have the necessary qualifications should work on the installation, commissioning, operation, and maintenance of the system.

Notes:

- Please read the product manual and properly follow its instructions
- Please read and follow the warning labels on the device
- Be aware of all national, state, and local requirements for accident prevention and environmental protection.

Proper Use

The SCU5 M controller is intended for indoor use only for use in industrial and lab equipment that process materials in web form as they move through a converting or raw material manufacturing process.

Improper Use

- Outdoor use or exposure to direct sunlight is considered improper.
- Any use outside the general specifications shall be considered improper use and voids any warranty of the equipment.
- Any replacement parts or modification necessities should be made by Roll-2-Roll Technologies LLC.

Static Discharges and Grounding

- Web, especially plastic webs, when transported over rollers can create significant static voltage potential. This static may discharge to the controller through the sensor cables. The static potential needs to safely discharged by proper grounding of the controller.
- Ensure that the sensor, the controller and all other devices connected to the SCU5 controller are properly grounded as well.
- Proper grounding can be ensured by checking for the continuity from any of the connectors on the controller and the earth ground.

OPERATION AND OPERATOR INTERFACE

Main Operator Interface Screen

The main operator screen provides relevant information and operator access for both the sensing and guiding application. The web guiding operations are accomplished using the web guide operation buttons on the bottom of the screen.

The capacitive touchscreen on the SCU5 controller uses a language independent icon based screen that allows ease of operation.

Never use sharp or pointed tools of any kind to operate the interface. Best practice is to have operators use their fingers to press the different icons. Care must be taken to clean the touch screen surface periodically.

Its icon based design allows for a language independent operation without the need of translation of the screen for setup and operation in different countries



Heartbeat Indicator

A round indicator at the bottom left of the operator interface indicates the heartbeat or the communication between the electronic controller board and the operator interface.

- This indicator is used for troubleshooting purposes.
- During normal operation this indicator will toggle between red and green at about 1 Hz.

NOTE: Slow heartbeat may indicate communication delay between the main motherboard and the touchscreen display/operator interface.

Web Detected Indicator

A small square indicator on the bottom left part of the screen indicates the presence and absence of the web as seen by the sensor in the respective mode of operation. When in edge mode the indicator turns green whenever the sensor sees a web edge. When in contrast mode the indicator turns green when the desired contrast is seen by the sensor.

This web detect indicator can be used for troubleshooting purposes. If this indicator turns off intermittently while a web is in front of the sensor it may indicate that the sensor is finding it difficult to accurately sense the web edge or the contrasting feature. This indicates a low contrast condition. Such a condition may occur for optical grade clear webs with low scattering in the infrared spectrum or when the desired contrast feature is not seen by the sensor.

Web Position Indicator

A horizontal bar graph, white bar in a black background, in the main operator interface is used to indicate the relative position of the web within the sensor range. The edge position or the contrast position is displayed using the white horizontal bar. The white portion indicates the web, specifically representing the light reflected/scattered back from a web, while the black background indicates the absence of web, specifically the darkness because of no reflection or scattering from the web.

Depending on the position and orientation of the sensor the white bar graph may move:

- from left to right for a sensor located on the right side of the web edge
- from right to left for a sensor that is located on the left side of the web edge.

When a wide sensor is connected and if the sensor is set to see both the edges, then both left and right edges of the web will be shown using the web position indicator. The vertical green line in the middle indicates the centerline position of the web.

When two sensors are connected, the bar graph will split in two, with the left half indicating the left edge of the web and the right half indicating the



right edge of the web. If both sensors are the same orientation, then web position from the sensor

connected to Sensor 1 port will be displayed on the left and the right half indicating the web position from the sensor connected to Sensor 2 port.

When in contrast mode the white bar graph may turn into gray segments representing the various contrasts on the web and the contrast position indicated by a vertical green line.

Sensor Position Indicator

The position of the sensor is indicated by two square indicators on the display that are located downstream of the web guide picture.

- The indicator turns green to represent the position and orientation of the sensor with respect to the web.
- If no sensor is connected to the SCU5 controller then both the indicators will turn gray.
- If two sensors (one right and one left) are connected or if a wide sensor in center mode, both indicators will turn green.
- It is important to ensure that the sensor position indicator accurately indicates the actual position of the sensor with respect to the web.
- The operator can find the correct position of the sensor by pressing the find sensor button. The find sensor button automatically detects the position of the sensor with respect to the web in the view of the sensor.

Find Sensor Button

The Find Sensor Button can be used to automatically detect the position and orientation of the sensor with respect to the web. Once the button is pressed the button will change state until a web is presented in front of the sensor.

- This button should be used whenever the sensor position is changed or when the edge orientation is changed.
- When the edge orientation changes, the bar graph will also change orientation.
- Find sensor button is activated only when the controller is in manual mode.

Automatic/Manual Icon







The SCU5 controller, for web guiding applications, can be put into manual or automatic operation mode by pressing this icon. The press of the icon will toggle the controller between manual and automatic operation. When the controller is connected to an actuator and a web guiding system, the automatic mode will move the web guide structure based on the position of the web.

A few icons on the operator interface are enabled or disabled as the web guide is switched between manual and automatic mode based on the available options in each mode. Figure on the right shows the operator interface while the controller is in automatic mode. The advanced setup and the find sensor buttons are disabled.

WARNING: Changing from one mode to another can result in a change in the web guide position causing process upsets. Caution must be exercised when changing the operating mode and should be done by those who completely understand the consequence of this change.

WARNING: No personnel should be manually handling the web guide or the material around the web guide when the guide is in automatic operation. Failure to follow this warning could result in crushing of body parts at pinch points around and within the web guiding system.



WARNING: Care must be taken that only one person is working on the guide when it is in manual operation. Failure to follow this warning could result in crushing of body parts at pinch points around and within the web guiding system.

NOTE: This functionality has no meaning for sensing application. However, some custom applications with custom firmware may use the functionality.

Servo Center Icon



Default/normal state



Servo-centering ON

Pressing the servo center icon will initiate the servo centering operation for web guiding applications. This operation can be performed only when the SCU5 controller is in manual mode. Pressing this momentary switch will initiate the servo centering operation which would toggle the icon to green. When the controller is in servo centering mode, the actuator connected to the SCU5 controller will move towards the home position or center position which is provided by the servo center sensor, typically an inductive proximity switch. As soon as the actuator reaches the home or the center position, the actuator will stop and the state of the momentary switch will change from Servo-centering (Green) to Default/normal state (Red).

The servo center feature allows the guide to be centered quickly to facilitate threading of the web during changeover.

WARNING: Servo centering operation results in a change in the web guide position causing process upset. Caution must be exercised when performing this function and should be done by those who completely understand the consequence of this change.

WARNING: Servo centering can be performed only when the web guiding system is in manual mode. Pressing the servo center icon during automatic operation will perform a different function.

WARNING: This is an automatic procedure of the web guiding system. No personnel should be performing manual work on or around the guide during the servo-centering procedure. Failure to follow this warning could result in crushing of body parts at pinch points around and within the web guiding system.

NOTE: This functionality has no meaning for sensing application. However, some custom applications with custom firmware may use the functionality.

Jog-left/Jog-right Icon



The Jog-left/Jog-right icons allow the operator to manually move an actuator connected to the SCU5 controller in either direction. These operations can be performed only when the controller is in manual mode. Both these icons act as a momentary switch that will turn ON (Green) when pressed and turn OFF (Red) when the released.

The Jog operation will continue as long as the button is pressed and will stop as soon as the button is released. This operation can only be performed when the guide is in manual setting.

WARNING: Jog-Left and Jog-Right operations result in a change in the web guide position causing process upset. Caution must be exercised when performing these functions and should be done by those who completely understand the consequence of this change.

WARNING: Jog-Left and Jog-Right operation can be performed only when the web guiding system is in manual mode. Pressing the icons during automatic operation will perform a different function.

WARNING: This is a manual procedure of the web guiding system. No personnel should be performing work on or around the guide during the jog procedure. Failure to follow this warning could result in crushing of body parts at pinch points around and within the web guiding system.

NOTE: This functionality has no meaning for sensing application. However, some custom applications with custom firmware may use the functionality.

Guide Point

The guide point is the desired reference position within the sensor window/range where the web needs to be positioned for web guiding applications. The guide point is the reference position which is used to compute the web position error for web guiding applications. When the web guide controller is in automatic mode the error between the guide point and the actual web position will drive the actuator inorder to minimize the error.

Typically the guide point is set to the exact middle of the sensor window/range. However, the guide point can be changed electronically to any location within the sensing window.

Guide Point Indicator

The guide point indicator which is on top of the web position indicator, provides a visual indication of the current guide point with respect to the sensor window/range. While in automatic mode, the web position will line up with the guide point indicator when the web guide is in normal operation.

Guide Point Offset

The guide point offset from the middle of the sensor window/range is displayed as a signed numerical value in millimeters. When the offset is 0 then the guide point is exactly at the middle of the sensor window/range. When the offset is positive then the guide point is on the right half of the sensor window/range while when the offset is negative then the guide point is on the left half of the sensor window/range.

Guide Point Adjustment

The guide point can be adjusted in two ways: fine guide point adjustment for small incremental adjustments and gross guide point adjustment for large step change to the guide point.

Fine Guide Point Adjustment

Fine adjustment to the guide point can only be made when the web guide is in automatic mode. These adjustments enable small incremental changes to the guide through the operator interface to enable operators to move the desired guiding position of the web. The fine adjustment to the guide point can be made by pressing the left (-) or right (+) arrow icons on the operator interface while the web guiding system is in automatic mode. Every single touch of the left or right icon will respectively decrease or increase the guide point by 0.256 mm. This change is immediately displayed by the visual guide point indicator and the numerical guide point indicator.



Pressing the middle icon (servo-centering icon) will reset the guide point to 50% or 0 mm guide point offset.

Gross Guide Point Adjustment

The gross guide point adjustment is intended for making a large step change in the guide point, often after a product changeover especially with a web width change. This adjustment can be made by directly sliding the visual guide point indicator track bar to the desired location; the track bar can be moved only when the web guide is in manual mode.

The change in the guide point needs to be confirmed by pressing the "Accept" button that appears whenever the track bar is moved. The confirmation is intended to prevent any accidental changes to the guide point. If the guide point change is not accepted within 10 seconds the



change will be disregarded and the previously accepted guide point will be restored.

NOTE: The pressing of the Left (-) or Right (+) during fine guide point adjustment will momentarily change the icon to green. With the release of the button the icon changes the color back to red.

WARNING: The guide point adjustment operation results in a change in the web guide position causing process upset. Caution must be exercised when performing this function and should be done by those who completely understand the consequence of this change.

WARNING: Fine guide point adjustment can be performed only when the web guiding system is in automatic mode. Pressing the Left (-) or Right (+) icons during manual operation will perform the jog operations.

WARNING: Guide point adjustment should be made only if it is necessary and should be carried out by

personnel with good knowledge about the consequences of the change. The performance of the guiding system may deteriorate if the guide point is too far away from the desired 50% setting. Some of the changes might have no effect if the web guide is in an extreme position.

Reset Guide Point

The reset guide point is intended to quickly change the guide point to the current web position. The feature is used in applications with frequent web width changes. Instead of manually moving the guide point using the gross or fine guide point adjustment, the guide point can be reset to the current edge position with the press of a button.



When in manual mode, pressing the reset guide point button will automatically set the new guide point to the current edge position as shown.

The change in the guide point needs to be confirmed by pressing the "Accept" button that appears whenever the reset guide point button is pressed. The confirmation is intended to prevent any accidental changes to the guide point. If the guide point change is not accepted within 10 seconds the change will be disregarded and the previously accepted guide point will be restored.

NOTE: This functionality has no meaning for sensing application. However, some custom applications with custom firmware may use the functionality.

Advanced Settings Menu

The SCU5 controller provides advanced settings both for the operator and the maintenance personnel. The advanced settings screen will allow operators, power users and maintenance technicians to adjust parameters to suit their measurement and web guiding needs. This screen can be accessed by pressing the Advanced Settings icon on the home screen.

Return to Main Screen

Access to these advanced screens can be restricted with passwords to prevent unintended changes to the settings by personnel not qualified to make such a change. Unique passwords are used for access to the operator screen and the power user/maintenance screen. The factory access is only

available to Roll-2-Roll Technologies personnel.

By default the password protection will be disabled and both the operator icon and the power user icon are visible to the user as shown on the right. If password protection is enabled the two icons would

disappear. The keypad can be used to type the appropriate password to gain access to the respective screen. Once the password is authenticated the respective icon would appear and touching the icon would provide access to the appropriate screen.

Operator Settings Screen

The operator settings screen provides a menu to the operator sensor screen and the operator width screen to set jobs for contrast sensing, contrast guiding and width measurement applications. The technical support contact information can also be viewed from the operator settings screen.

Operator Sensor Screen

This screen provides access to several sensor functionalities that provide the user with complete control over the sensor image processing of the controller. Hence it is critical that the user is familiar with all the functionality to ensure proper operation of the controller.

Sensor Mode

The operator can change the sensor mode from edge sensing to contrast sensing by toggling the sensor mode button. When the icon is black and white the controller operates in edge sensing mode. When the icon is black, green and white then the controller operates in contrast mode.

NOTE: If two sensors are connected to a single controller, the controller will process both the sensors with a single mode of operation. In other words the two sensors cannot have different modes of operation.

Thresholding Mode

Thresholding mode can be set to either static or dynamic. For most applications the default dynamic thresholding (green icon with varying levels) would be the most appropriate choice. However, for some advanced applications the static thresholding (red icon with a flat line) could be used. This advanced feature should be used with caution.

NOTE: Each sensor can have its own independent thresholding mode.

Sensor Selection

Pressing the sensor selection button would allow the user to access the settings for the respective sensor. The button press will toggle between Sensor 1 and Sensor 2.

Minimum Contrast Gauge

The minimum contrast that is required to detect an edge can be set using this contrast gauge and the corresponding numerical integer value is displayed to the right of the gauge. When the contrast value is lowered the controller becomes sensitive to small contrast changes in the image captured by the sensor. Hence more and more edges with low contrast will be picked by the controller. When the contrast value is set high, the edges with high contrast values will be seen while the low contrast edges would be disregarded.

The recommended minimum contrast value for edge mode is 10 and for contrast mode is 50.

NOTE: Set the minimum contrast as high as possible while the feature of interest is still visible. This will increase the robustness of the algorithm.

NOTE: When the thresholding method is static then the minimum contrast value directly corresponds to a scaled static threshold.

NOTE: Under certain conditions the user will not be permitted to change the minimum contrast value. This will occur in contrast mode when the controller is taught to track a certain feature on the web.

WARNING: If the sensing mode is contrast and if the minimum contrast value is too low or zero then the contrast detection algorithm will not function properly and would perceive every small change in the image. For contrast mode the recommended default value is 50.

WARNING: If the sensing mode is edge and if the minimum contrast value is too low or zero then the edge detection algorithm may pick only one edge even if multiple edges are present. For edge mode the recommended default value is 10.

Brightness Gauge

When the brightness control is set to be in freeze mode, the gauge can be used to manually set the brightness. The corresponding numerical integer value is shown on the right of the gauge. The brightness can be changed from 0% to 100%.

NOTE: This feature is intended for advanced users and by default the brightness control should be allowed to change automatically.

Brightness Control

The controller has an automatic brightness control algorithm that will change the brightness of the LEDs in the sensor based on the captured image. The algorithm helps to capture the best possible image based on certain criteria. The algorithm also helps with background suppression. The user can disable the automatic brightness control algorithm to gain manual control over the LED brightness. Pressing the brightness control button will toggle the state of the brightness control algorithm to either automatic or freeze.

NOTE: This feature is intended for advanced users and by default the brightness control should be allowed to change automatically.

Live Processed Image Preview

The rectangular box on the top shows a grayscale live preview of the processed image seen by the sensor. The different shades of contrasts seen by the sensor appear as rectangles in the image preview window. When a region of the web scatters a low amount of light back to the sensor, the region appears black or dark; while the region that scatters more light appears white or light. The grayscale value corresponds to the average light intensity within each region.

Selected Feature

The controller can be taught to track a certain feature using one of the contrast modes. During teaching and after teaching, the selected feature that is being tracked is highlighted by a green bounding box. Depending on the contrast mode the bounding box may be a rectangle, three sided rectangle or two three sided rectangles.

NOTE: If the taught feature is not seen within the sensor window then no bounding boxes will be visible. This would correspond to no valid contrast condition.

Feature Navigation

The left and right arrow keys can be used to scroll through the live processed image preview to select the appropriate contrasting feature of interest. Depending on the contrast mode chosen the arrow keys will move the edge or the line to the left or to the right.

NOTE: The feature selection key can be used only when the controller is in teaching mode.

Teaching

When the controller is in teaching mode, the gear icon will appear green. The user can press the left and right feature navigation keys to navigate to the feature of interest. To save the teaching, so that the controller can follow the feature of interest, the gear icon can be pressed again. Successful teaching and saving of the feature of interest will turn the gear icon to red and all the contrast mode icons will disappear, except for the selected contrast mode.

WARNING: When teaching is saved, the controller will look for the first appearance of the feature of interest from left to right. If there are two features with the same conditions within the sensor view, the left most feature would be selected. It is highly recommended to teach on a unique feature in the sensor view to increase the robustness of the measurement.

Contrast Mode

Four different contrast modes are available for the user to pick when the controller is in teaching mode. These include right edge of a color (or grayscale), edge created by two colors, the position of a line with a certain color, and left edge of a certain color. When a certain mode is selected the region of interest is highlighted in the icon as shown below. When the teaching is successfully saved, the icon corresponding to the selected mode will be visible on the screen while all other three mode icons would disappear.

WARNING: If the teaching is not successful or if an invalid feature is picked then all four icons will be visible on the screen. Successful teaching will make three mode icons disappear while leaving one visible.

Right edge of a color

In this mode the controller will look for the right edge of a certain color (or grayscale) as shown below. A three sided open rectangle will highlight the region of interest with the right edge of the color region highlighted in green. The user can press the feature navigation arrows to navigate to the region of interest. When the desired region of interest is highlighted, the teaching can be saved by pressing the gear icon. Once the teaching is saved, all other modes will disappear and the gear icon will turn red as shown below.

NOTE: In the above example the user cannot navigate to the rightmost region since the controller cannot see an edge for that color. The user will only be able to navigate to the middle black region.

NOTE: If more than one feature has the same color, the controller will only pick the first right edge with that color from left to right. It is not recommended to use this mode if two features on the web have the same color; Line mode or edge created by two colors may be a better option.

NOTE: When the teaching is successfully saved, indicated by the disappearance of all other mode icons, the user cannot change the brightness control state, the brightness gauge or the minimum contrast gauge.

Edge created by two colors

In this mode the controller will look for an edge created by a certain color on the left and certain color on the right. Two regions will be highlighted along with the edge that is of interest (as shown below). The controller will look for the first appearance of the exact match of the edge with the two colors on either side with the appropriate order. Once the teaching is saved, all other modes will disappear and the gear icon will turn red.

Edge with two colors (Teaching)

Edge with two colors (Teaching Saved)

NOTE: The Order of the colors matters in this mode. In the above example if the sensor is taught from gray followed by black and if the order is reversed to black followed by gray (if the sensor is rotated 180°), the controller will not pick that edge even though the two color regions are the same.

NOTE: If multiple regions have the same color pair (such as in a barcode), the controller will always pick the first pair from left to right. In that case the right edge of the color mode would be a better choice.

NOTE: When the teaching is successfully saved, indicated by the disappearance of all other mode icons, the user cannot change the brightness control state, the brightness gauge or the minimum contrast gauge.

Color of a line

In this mode any region with two edges can be used for tracking purposes. The controller will look for two conditions to track the feature: (1) color and (2) the width of the color region. Since two conditions need to be satisfied, this is one of the most robust modes. Once the teaching is saved, all other modes will disappear and the gear icon will turn red. Once the teaching is saved, the controller always pick the first occurrence of the color with a certain width while scanning from left to right

NOTE: In the above example the user cannot navigate to the rightmost region or the left most region since the controller cannot see both the edges for that color. Two edges for the certain color should be seen for the controller to lock on the line feature.

NOTE: If there are two lines with the same width and same color the controller will always pick the first matching line from left to right.

Left Edge of a color

Similar to the right edge of a color, this mode will allow the user to track the left edge of a certain color. In teaching mode, a rectangular region of interest and the left edge of that region will highlight the region. Once the desired region is selected the teaching can be saved by pressing the gear icon. If the saving is successful all other modes will disappear and the gear icon would turn red.

NOTE: While teaching, the controller will not scroll through a region without a proper definition of the feature in that respective mode. For example, the user cannot pick and teach for the leftmost region on the screen while in the left edge of a color mode. This is because the leftmost edge cannot be outside the

sensor viewing area. Similarly the controller will not pick the leftmost or rightmost region when in line mode since for a line both edges need to be visible in the sensor viewing area.

WARNING: While teaching, the controller would allow the user to pick a non-unique region of interest. However, after teaching the controller will always track the first occurrence of the non-unique region while scanning from left to right.

NOTE: No region will be highlighted if the feature of interest is not in the field of view of the sensor. This condition is called the "No Contrast" condition.

NOTE: While in automatic mode for web guiding, the web guide will automatically go to an interlock mode and will prevent the web guide to actuate whenever a no contrast condition is seen. As soon as the feature of interest reappears the web guide will actuate if the position of the feature is not at the desired guide point.

NOTE: When no contrast condition occurs, the analog output will provide the middle value of its output range. The digital output through ethernet would have a number equal to the total number of pixels in the sensor. Under normal operation, the digital contrast position output would range between zero and (number of pixels – 1). Whenever the value equals the number of pixels then it means no contrast condition.

Operator Width Screen

For width measurement applications the operators can set the job by navigating to the width menu on the operator settings screen. If one sensor is used for width measurement, the controller should be in edge mode with sensor configuration to be in center sensor. If two sensors are used to measure web width, then the sensor should have the corresponding left and right sensor configuration for the respective edge of the web. It is also possible to measure (1) the width of a contrasting feature with two sensors, and (2) the width of two strips of web with two sensors. Please consult the factory for these advanced functionality.

Nominal Width

For each job the operator can set a nominal width (in millimeters) by pressing the nominal width button. When the button is highlighted in green the operator can change the value by using the -ve (left arrow) and +ve (right arrow) arrows on the bottom. Depending on the magnitude selected (pressing the appropriate magnitude value will highlight the button to green) each press can change the value by 0.25 mm, 1 mm, 10 mm or 100 mm. The nominal width value is used to compute the width error based on the measured width.

NOTE: The minimum value for nominal width that can be set is 1 mm and the maximum value is 9750 mm.

NOTE: When the width is more 99.75 mm the display will only show one decimal place even though the nominal width can be set to any multiple of 0.25 mm. Similarly when the nominal width is more than 999.75 mm the display will only show integer values. However, if the nominal width is incremented by 0.25 mm increments, the controller will still record those without displaying the decimal places.

Upper Limit

When the measured web width is more than the nominal web width then the width error is positive. With an appropriate output on the SCU5 controller a fault signal can be generated when the positive width error is more than the upper limit. If the error is equal to the upper limit, no fault signal would be generated.

NOTE: The controller will not check to see if the upper limit is more than the nominal width.

NOTE: The minimum value for the upper limit that can be set is 1 mm and the maximum value is 99.75 mm.

Lower Limit

When the measured web width is less than the nominal web width then the width error is negative. With an appropriate output on the SCU5 controller a fault signal can be generated when the negative width error is less than the lower limit. If the error is equal to the lower limit, no fault signal would be generated.

NOTE: The controller will not check to see if the lower limit magnitude is more than the nominal width.

NOTE: The minimum value for the lower limit that can be set is 1 mm and the maximum value is 99.75 mm.

Measured Width

The measured width provides a real time width value based on the image captured by one or two sensors. The measured width is the sum of raw measurement from each sensor plus any offset. Offset is often necessary when the width is measured with two sensors. Since the controller does not know the actual distance between the two sensors, the offset is necessary to compute the measured width based on the raw width measurement from the sensor(s).

NOTE: The measured width will update only with correct settings. For example, if one sensor is connected and the sensor is set to left mode, the measured width value will not update.

One Sensor

When one sensor is used for width measurement, the sensor should be wide enough to see both the edges of the web even when the web wanders in the cross-machine direction (width wise movement). The sensor mode should be in edge mode with the sensor configuration to be in center to see both the edges. The measured width is the raw width plus the offset. The offset is still valid for one sensor however it may be a small value. The offset is used to compensate for working distance and focus corrections.

Two Sensors

When two sensors are used for width measurement, each sensor should be installed with appropriate orientation, i.e., one sensor should see the left edge of the web and the other the right edge. For most applications the sensor mode should be in edge mode. The measurement from each sensor is the amount of web seen by each sensor, which is the raw width. If the two sensors are exactly butted against each other

then the sum of the two sensors would be the web width. If the two sensors overlap each other if they have a gap between them, then the offset is either negative or positive. Hence the measurement width would be the sum of web covered by each sensor plus the offset.

NOTE: If both the sensors are in the same orientation the width measurement would still work but the display on the front screen would show both edges moving in the same direction with a black gap in the middle.

NOTE: If sensing mode is contrast, the two sensors have to be positioned a certain way to get the correct contrast width measurement. Please consult the factory for more detailed documentation for such an installation.

Teaching

When the user presses the teaching wand, the controller will automatically calculate the offset based on the raw sensor(s) measurement at that instant. The offset is computed by subtracting the raw sensor(s) measurement from the nominal width.

In order to record the correct offset the user should present a web of known width (preferably the known width is equal to the nominal width) at the desired working distance from the sensor(s), ensuring that both edges of the web are seen by the sensor(s). If that known width is different from the nominal width, then that value can be entered as the nominal width before pressing the teaching wand. As soon as the wand is pressed, the controller will calculate the offset. If the nominal width is different from the known width used for teaching, then the appropriate nominal width can be reset.

NOTE: When the teaching wand is pressed the controller will compute the offset using this equation: offset = nominal width - raw measurement from the sensor(s). The offset is not shown on the display however the measurement width will be shown. Since the measured width is offset plus the raw measurement from the sensor(s), the measured width will be the same as the nominal width (if the web is stationary).

WARNING: Pressing the teaching wand will reset the offset based on the current measurement.

NOTE: The offset can be reset to zero by pressing the teaching wand when no web is in front of the sensor(s).

Output Type

When an analog output is used for width measurement, the analog output type can either by the absolute width measurement or the error in width measurement. Pressing the button will toggle the state between the absolute and error output.

Absolute

When the output is set to absolute, the digital width measurement displayed on the home screen will provide the measured width value in mm. The analog output on the other hand would be scaled to range from null scale to full scale based on the range of the sensor and the range of the analog output. For example, with a 48 mm sensor a web width of 24 mm would have an analog output value of 5 V if the analog

output range is set to 0 to 10 V. However, the same 24 mm width for a 112 mm sensor would be 2.14 V if the analog output range is set to 0 to 10 V.

NOTE: The user has to scale the output to convert the output into an absolute width value based on the sensor range.

Error

When the output is set to error, the digital width measurement displayed on the home screen will provide the error between measured width value and nominal width value in mm. The analog output on the other hand would be scaled to range from null scale to full scale based on the error. If the error is zero then the analog output would be exactly one half of the full scale range of the analog output. For example, if the analog output range is 0 to 10 V the output would be 5 V if error is zero. If the error is positive then the output would be more than 5 V and if the error is negative then the output would be less than 5 V. Unlike the absolute output type, the magnitude of error in mm and the magnitude of voltage change on the analog output would not change based on the sensor range. For example, if the error is 2 mm irrespective of the sensor range the analog output would always be ...

NOTE: The analog output setting (which can be set as shown in the following sections) should be set to width inorder for the width measurement to function properly.

NOTE: It is intuitive to see the output when the voltage ranges to ± 10 V or ± 5 V for this mode.

Power User Screen

When the power user icon is pressed on the advanced settings menu, the power user is presented with a menu of options. These options include settings for the actuator, sensor, controller, analog output, password protection and communication. Access to the respective settings are available by clicking the respective icon.

WARNING: Changes to these settings can have a significant effect for both sensing and guiding applications. Wrong settings can cause damage to the actuator, web guide or devices connected to the SCU5 controller. Hence only those well versed in the operation of the web guiding system or the measurement/sensing system should change these settings.

Actuator Setting

The actuator setting screen allows the power user to set the actuator parameters such as stroke length, lead screw pitch, actuator speed, acceleration, the motor polarity and the servo center polarity.

WARNING: The actuator parameters are typically preset from the factory and should only be changed with consultation with the factory. Except for speed and acceleration all other parameters need not be changed once the web guiding system is commissioned for operation.

NOTE: The actuator parameters are intended to be changed by maintenance personnel with sufficient knowledge about the web guiding system and its performance. Most often these settings are changed during initial commissioning, after an actuator upgrade or replacement and/or with after a retrofit installation.

Stroke

The digital stroke length can be changed in multiples of 5 mm and can be incremented or decremented using the + and - keys. This digital stoke setting is used to keep track of the distance the actuator can move on either side from the servo centered position. Hence from the middle position (servo centered position) the actuator will travel half the stroke length on either side. This digital stroke length setting helps prevent the actuator from hitting the mechanical limits and prevent any motor damage in the event that the actuator moves when no web is present.

NOTE: The actuator position is tracked digitally using software and the actuator stops actuating once the digital limits are reached. The digital limit of the actuator may not correspond to the physical limits of the actuator or the web guide structure. These digital limits are available to prevent the actuator from hitting the mechanical limits and to avoid any possible motor burnout.

WARNING: Never set the stroke length more than the physical stroke length of the actuator. Setting a stroke length more than the physical stroke available in the actuator may cause actuator damage.

WARNING: Never set the stroke length more than the physical stroke length available on the web guide structure. Setting a stroke length more than the physical stroke available may cause actuator damage.

NOTE: The servo center position is used to reset the digital position count to zero whenever the actuator reaches the servo center position.

Pitch

The pitch setting is used to set the lead screw pitch. This setting is pre-set at the factory and should not be changed without consultation with the factory. The pitch can be incremented in multiples of 0.25 mm.

WARNING: Changing the pitch setting would affect the digital position count of the actuator and hence the effective stroke of the actuator. Setting the pitch higher than the actual pitch would reduce the effective stroke length and vice versa.

WARNING: Never set the pitch to a value that is less than the actual pitch. This can result in the actuator reaching its mechanical limits and possible actuator damage.

Motor Polarity

The motor polarity setting is used to reverse the direction of the actuator. This setting changes the behavior of the actuator both in automatic mode as well as in manual mode. Depending on the sensor installation the motor polarity needs to be reversed to make sure that the automatic correction is in the right direction.

WARNING: If the motor polarity is set incorrectly the web guide structure will move in the opposite direction of the desired correction when in automatic mode. This is an immediate indication of the incorrect setting.

Servo Center Polarity

The polarity of the servo center can also be changed in order to accommodate various locations for the sensor installation. This may be necessary if the location of the servo center is changed or if a different type of servo center sensor is used.

WARNING: If the servo center polarity is set incorrectly the actuator will move away from the middle position when the servo center button is pressed. This might cause the actuator to hit the mechanical limits and might cause damage to the actuator.

Speed

The actuator speed can be increased or decreased using the slider. The value set indicates the percentage of the maximum and minimum speed setting for the actuator.

WARNING: When the speed is set to 0% the actuator will not respond in the automatic mode.

Acceleration

The actuator acceleration can be increased or decreased using the slider. The value set indicates the percentage of the maximum and minimum acceleration setting for the actuator. Higher acceleration may result in lower thrust output from the actuator.

WARNING: When the acceleration is set to 0% the actuator will not respond in the automatic mode.

Sensor Setting

Power users have the ability to change several settings for each sensor to enable advanced capability of the controller. These settings include the ability to turn on and off the automatic brightness control algorithm, manually set the brightness of sensor(s) LEDs, enable or disable the sensor that is connected to a controller and manually force the position state of the sensor(s).

Automatic Brightness Control

One of the advanced features of the controller is to automatically adjust the brightness of the LEDs in the sensor for background suppression purposes. The default factory setting is to have the automatic brightness control ON. However, the power user has the ability to freeze and manually set the brightness to an arbitrary value depending on their application needs. Pressing the brightness icon will toggle the state between Automatic and Freeze.

WARNING: Disabling the automatic control should be performed only for challenging applications where the automatic brightness control is not performing as desired. This operation should be carried out only by those who have good knowledge about the application.

WARNING: Manually setting the brightness too high would disable the background suppression algorithm so this should be carried out only by the power user who is knowledgeable and aware of its consequences.

WARNING: Manually setting the brightness too low may prevent the controller from seeing the web. Never set the brightness to zero without consulting the factory about the application.

NOTE: If the sensor mode is set to contrast then the state of this button cannot be changed.

Brightness Value

The percentage brightness of the LEDs is displayed as a three digit integer and using the brightness gauge. If the brightness control is disabled (or in Freeze mode) then the user can manually set the brightness of the LEDs for the respective sensor.

NOTE: If the sensor mode is set to contrast then the brightness cannot be changed manually.

NOTE: If the sensor mode is set to edge and the automatic brightness control is enabled then the brightness cannot be changed manually.

Enable/Disable Sensor

For certain applications it may be necessary to disable a sensor that is connected to the controller. An example application would be one in which two sensors, located at two positions or locations, are used to control a single web guide structure or an actuator. However, only one sensor is used at a time for the feedback control.

By default both sensors are enabled as part of the default factory settings. Pressing the button will toggle the state between enabling and disabling the sensor. Bright lime green indicates that the sensor is enabled while a dull green indicates that sensor is disabled.

WARNING: Unless the application requires the sensor(s) to be disabled, always leave the sensor(s) enabled with the factory default setting.

NOTE: Disabling a sensor electronically will have the same effect as unplugging the sensor physically.

Sensor Position/Orientation Setting

Power users also have the ability to force the sensor position/orientation state depending on their application. The states can be one of the following: Auto, Left, Center or Right. When the state is set to Auto the find sensor button on the front screen can be used to automatically detect the sensor position/orientation based on how the web is presented. For certain situations the user may prefer to manually set the state of the sensor to Left, Right or Center.

In edge sensing mode the sensor will look for the web edge scanning from the outside to the inside of the sensor. For a left sensor the scan goes from left to right, while for a right sensor the scan goes from right to left. A center sensor state is one in which both the edges of a web are within the field of view of the sensor.

Left sensor orientation (left) and right sensor orientation (right)

NOTE: The sensor state is always defined based on relative position of the web with respect to the sensor. For example, in the picture on the left above if the sensor is rotated upside down, which the cable gland on the top, then the sensor orientation would change to right sensor.

WARNING: If the sensor state is forced to Left, Right or Center, disconnection and reconnection of the sensor will not automatically set the state as in the Auto mode. Everytime the sensor position is changed, with respect to the web, the power user is responsible

for ensuring the correct state of the sensor.

Controller Setting

When the SCU5 controller is used for web guiding purposes the controller settings such as gain, deadband, etc.can be set from this screen.

Gain

The gain setting needs to be changed based on the actuator lead screw and the mechanical advantage of

the web guide structure. The gain value sets the maximum distance the actuator would move based on the error magnitude. Unlike conventional controllers, the Roll-2-Roll SCU5 web guide controller is a complex non-linear position based controller which has independent settings for position gain, velocity and acceleration of the actuator. The maximum stable gain setting for the actuator or web guiding system depends on the pitch of the lead screw, the microsteps of the driver, the mechanical advantage of the web guide structure. Typically the controller is preset with the recommended gain values from the factory.

NOTE: If the gain is set to zero then the actuator will not respond to any error when in automatic mode.

NOTE: The gain setting is independent of the speed and acceleration setting.

WARNING: This parameter may affect the stability of the overall web guiding system and hence should be changed with care.

Deadband

Deadband is the region around the guidepoint where the actuator will not be actuated if the web is within this deadband. This integer value is in pixels and by default the deadband value is 4 pixels or 0.25 mm. With that setting, the actuator will not move if the web is within \pm 4 pixels or \pm 0.25 mm from the guidepoint. Setting a deadband of zero will make the actuator move as long as the error is non-zero.

NOTE: Wider deadbands can be used for webs with ragged or irregular edges.

NOTE: Setting the deadband to zero will make the actuator move all the time. It is not advisable to set the deadband to zero.

Lock on Lost Edge

For some applications it may be necessary to prevent the actuator from moving when a web edge is not seen within the sensor window. By setting this parameter to ON the actuator will stop moving when no web is seen by the sensor. This is similar to the automatic interlock mode that is available in the contrast guiding application

NOTE: This setting is only applicable for edge guiding application since it is by default implemented for contrast guiding.

NOTE: This setting is only applicable for single edge guiding with one sensor since it is by default implemented for center guiding with one or two sensors.

NOTE: The actuator will move if the web is completely covering the sensor window. And the actuator would stop moving only when no web is seen by the sensor. When two sensors are used both the sensors should see no web for this feature to function.

Servo Center

The servo center functionality is typically implemented with an inductive proximity sensor that looks for the home/middle position. It is possible to disable the use of an external proximity sensor and just use the internal motor position counts. This parameter enables or disables the use of an external proximity sensor

for servo centering purposes. It is always recommended to use an external servo center sensor since the sensor will reset/recalibrate the position tracking of the controller.

WARNING: If an external servo center sensor is enabled but no servo center sensor is installed, the actuator will still move until the physical limit is reached. This might cause the actuator to hit against its mechanical limit and can cause damage to the actuator. However, the controller will automatically recognize the absence of the servo center sensor and will perform a different routine to bring the actuator back to the middle of its stroke. This might take a while depending on the actuator stroke and speed settings. If the controller does not find the servo center sensor, it will automatically switch the servo center sensor back to OFF.

WARNING: If servo center polarity is set incorrectly, the controller will perform the above routine. Hence if that happens the servo center polarity has to be reversed before turning this servo center switch back ON.

WARNING: If the inductive proximity sensor is installed too far away from the target to actuate the switch the servo center routine may not find the home/middle position.

NOTE: If the servo center switch is turned off, pressing the servo center button would move the actuator to the digital home/middle position. This position may not be the home/middle position for the actuator.

Limit Switches

For high dynamic response or high load applications, where the controller is pushed to get the best possible speed and acceleration performance, it may be necessary to install physical limit switches since the digital position count from the controller may not be accurate. In those cases the limit switch can be turned ON. Alternatively, for safety application these limit switches can be used to stop the actuator from moving when a guard door is open.

NOTE: Disabling the limit switch will only disable the physical limit switch. The electronic limit based on the actuator stroke will still be enabled to stop the actuator from moving if the position count is reached electronically.

NOTE: If the limit switches are used for safety application both the left and the right limit switch should be connected together to a single actuator inhibit signal.

WARNING: If the limit switch is enabled but the physical switches are not installed correctly, then the actuator will not move at all. Even the Jog and Servo Center functionality will be disabled.

Analog Output Setting

Output range selection

The analog output setting can be changed based on the application. The voltage ranges and the current

ranges can be set by picking the appropriate selection. The available voltage options are 0 to 5 V, 0 to 10 V, \pm 5 V and \pm 10 V. The available current options are 0 to 10 mA, 0 to 20 mA, 0 to 24 mA and 4 – 24 mA.

NOTE: Any combination of the voltage and current setting can be selected, except when 0 – 10 mA is selected the voltage output is automatically set to 0 – 5 V.

Analog mode

While in edge mode the controller can be programmed to provide the position of the left edge, or right edge or centerline position or the web width. The analog mode can be changed only if the sensor sees both edges of the web. Selecting the appropriate analog mode button will enable the user to accomplish the functionality.

NOTE: When only one edge is seen by the sensor or when the sensor is in single edge mode, the analog mode cannot be changed. The controller will automatically select the appropriate edge and by default will provide the single edge position through the output.

WARNING: For width measurement application, the analog mode should be set to width even if the controller is not equipped with an analog output port.

WARNING: Analog mode cannot be changed if the controller cannot provide the appropriate output.

Analog setup

The controller can be programmed to provide the zero scale value or full scale value by pressing the appropriate button. This functionality is useful while calibrating a legacy system. After calibration the controller can be switched back to normal operation by clicking on the Normal Op button.

NOTE: The controller will switch back to normal operation as soon as the user leaves the analog setup screen.

Password Setting

This screen allows the power user to enable or disable the password protected for both the power user screen access and operator sensor screen access. Pressing the button will toggle the password enable/disable option. When the locked icon is displayed, the password for the respective screen will be enabled. Power User Operator

NOTE: Please contact the factory for the passwords for the respective screens.

NOTE: The passwords for the respective screens cannot be changed. However, if a custom 4 digit password can be created with a customer firmware change.

Communication Setting

For the controller with industrial ethernet, the power user can enable or disable the industrial ethernet communication. The state can be changed by pressing the ON/OFF icon on the screen.

NOTE: The state change from OFF to ON requires a power cycle of the controller to enable and start communication with PLC or other industrial ethernet device.

NOTE: Any change on this screen requires a power cycle of the controller.

NOTE: If a digital output is available on the controller, then this communication button should be off for the digital output to function properly.

For firmware version 3.4a and above the communication screen would have the ability to set the network information from the controller. This screen provides the ability to view and change the network information of the SCU5 controller.

Ethernet

The ethernet ON/OFF button is the same as the communication ON/OFF from the previous versions of the firmware. This switch must be ON for the ethernet module on the SCU5 hardware to initialize.

NOTE: The state change from OFF to ON requires a power cycle of the controller to enable the initialization of the

ethernet module to start communication with PLC or other industrial ethernet device.

NOTE: If a digital output is available on the controller, then this ethernet button should be off for the digital output to function properly.

DHCP

If the DHCP is set to ON the SCU5 controller (client device) will get the IP address from a network server or a router. The IP address, and other network parameters, would be assigned dynamically and may change after a power cycle if the server or router initiates the change. When the DHCP is set to OFF then the controller will use a static network information (such as the IP address, subnet and gateway) that is set on the controller manually.

Ethernet ON	DH	CP	DFF	FTP	OFF
	IP	192	.168.	001.0	05
REFRESH	SN	255	.255.	255.0	00
EtherNet/IP	GW MAC	10 9-11			
Network	1	2	3	4	5
$\langle \gamma \rangle$	6	7	8	9	0

NOTE: The state change from OFF to ON requires a power cycle of the controller.

NOTE: The DHCP can also be set using the IPConfig utility or other network software directly through the network.

FTP

This setting would enable or disable the FTP server on the SCU5 controller. This is an advanced feature and should not be changed without consulting with the factory.

NOTE: The default state is OFF.

IP

The IP address of the SCU5 controller can be viewed and changed here. If the IP address button is pressed it will allow the user to set the IP address. The user will be able to set a valid 32-bit address value by entering four 8-bit values (3 digits each) using the keyboard. The address can be set by pressing the set button which will appear when a valid IP address is entered.

Ethernet ON	DHO	CP	OFF	FTP	OFF	Ethernet ON	DHO	CP	OFF	FTP	OFF
EtherNet/IP	IP SN GW MAC	_00 255 192 00-	0.000. 5.255. .168.0 30-11	000.0 255.0 001.00 -24-E	00 00 00 00 09-11	SET EtherNet/IP • Network	IP SN GW MAC	192 255 192 00-	2.168. 5.255. .168. 30-11	001.1 255.0 001.0 -24-E	00 00 00 9-11
• Network	1	2	3	4	5		1	2	3	4	5
$\langle \mathcal{A} \rangle$	6	7	8	9	0	\sim	6	7	8	9	0

Subnet Mask and Gateway

Both the subnet mask and the gateway for the network can be viewed in a similar fashion as the IP address. Same rules for setting these parameters are applicable.

NOTE: Changing the IP address, subnet mask and/or gateway requires the controller to be power cycled.

NOTE: If any of the 3 digits is more than 255 the digits do not correspond to a valid 8-bit number. The whole address would be reset to zero and the user would have to start entering the numbers again.

NOTE: Entering a valid 8-bit number in each field does not mean that the value would be accepted by the network. The network constraints should be followed for these settings to take effect. The only way to verify that the new settings were accepted is by power cycling the device.

NOTE: The refresh button is useful only when any of the settings are changed by a network device or through the network. Changing the settings through the SCU5 controller and hitting refresh will not change the settings unless the controller is power cycled.

NOTE: The set button will appear only after successful entry of the respective values. All the three fields can changed before pressing the set button.

MAC address

The MAC address of the ethernet module on the SCU5 controller is displayed here. This value cannot be changed.

Module Type

The type of the industrial ethernet module in the SCU5 controller will be printed over the network LED. The available fieldbus options are EtherNet/IP and PROFINET. If no module is available on the SCU5 controller then the module type would be None.

Network Status

If the ethernet module on the SCU5 controller communicates and exchange data between itself and a PLC then this led will turn green. If no such communication occurs then the led will be red in color.

NOTE: SCU5 controller ethernet module can still be a valid device on the network even when the network status led is red. The module can still be accessed through TCP/IP or UDP as long as a valid IP address and other network information are present.

NOTE: If all of the address fields and the mac address is zero, then the ethernet module is not initialized. Make sure to turn ON ethernet and power cycle the controller. If the problem persists, you may not have an ethernet module on your controller or the ethernet module on the controller is faulty. Please consult the factory for more information.

REMOTE CONTROL AND MONITORING

A set of input and output registers are available to monitor and control the web guide controller remotely using industrial ethernet communication such as EtherNet/IP or PROFINET. The remote control and monitoring is available for advanced end users, OEMs and integrators to seamlessly integrate the web guide controller into their existing machine. For more information about these advanced features please consult the factory. It is possible to control/operate the web guide controller without an operator interface and directly using the industrial ethernet connection. The following section describes the advanced settings for industrial communication.

Output registers

The output registers from the controller provide information about the sensor(s) and the web guide controller. The data includes status/fault information, sensor position information and sensor measurement quality information, web guide fault information, motor speed information and the current guide point information. The data from the controller is organized in the following registers:

Register #	bit 15	bit 14	bit 13	bit 12	bit 11	bit1 0	bit 9	bit 8	bit 7	bit 6	bit 5	bit 4	bit 3	bit 2	bit 1	bit 0
0		Sensor 1 status/fault register														
1		Sensor 2 status/fault register														
2							Senso	r 1 pos	sition o	output						
3		Sensor 2 position output														
4	Sensor 1 quality factor								Sensor 2 quality factor							
5		Web guide status/fault register														
6		Guide point offset														
7		I	Notor	speed	perc	entage	2			Mot	or acc	celerat	tion pe	ercent	age	

Sensor status and fault registers

The sensor status/fault register is organized as follows. The eight least significant bits correspond to fault information while the eight most significant bits correspond to status information.

Bit #	Value	Label	Description
0	0/1	No sensor	0: if a sensor is present
			1: if no sensor is connected

1	0/1	Low contrast	0: if measurement contrast is high 1: if measurement contrast is low
2	0/1	No web	0: if web is detected by the sensor 1: if the sensor cannot detect a web
3	0/1	Wrong orientation	0: if sensor orientation is correct 1: if the sensor see an edge in the opposite orientation to which it is set up
4	0/1	Poor Edge quality	Advanced feature not in all controllers.
5	0/1	Flutter	0: if no flutter is detected 1: if the sensor detects flutter or out of plane movement in the web
6	0/1	Malfunction	Advanced feature not in all controllers.
7	0/1	Dust	Advanced feature not in all controllers.
8	0/1	Left Sensor	O: if the sensor not set as a left sensor 1: if the sensor is set as a left sensor
9	0/1	Right Sensor	0: if the sensor not set as a right sensor 1: if the sensor is set as a right sensor
10-13	O-15	Number of pixels	The number of pixels in the sensor and the corresponding sensor resolution. 0: 256 WPS 16 (0.0635 mm) 1: 768 WPS 48 (0.0635 mm) 2: 1774 WPS 221 (0.125 mm) 3: 896 WPS 112 (0.127 mm) 5: 1792 WPS 112 (0.0635 mm)

			6: 1774 WPS 221 (0.127 mm) 7: 3548 WPS 221 (0.0635 mm)
14-15	0/2	Sensing mode	0: edge sensing mode 2: contrast position sensing mode

Note: If both the left sensor and the right sensor bits are set then the configuration corresponds to center sensor mode. A single sensor may be used to measure the position of the two edges of the web, if the width of the web is smaller than the sensing window of the sensor.

Sensor position output register

The sensor position output register provides the absolute measurement in pixels. The output ranges from 0 to the number of pixels in the sensor, and depending on the sensor mode (edge or contrast) the output corresponds to edge position or contrast position. In order to convert the position into a physical unit, such as millimeters or inches, the sensor resolution and the total pixel number of the sensor head are necessary. In either sensor orientation (left or right) the measured position increases as the web moves from left to right.

NOTE: The output when the web completely covers the sensor or when the web is completely outside the sensor window will be different based on the sensor orientation.

NOTE: If no sensor is present then the value in the sensor position output register is meaningless.

NOTE: If a sensor acts as a center sensor, the center line position will be output via the industrial ethernet.

Quality factor registers

The quality of the sensor measurement from the two sensors are provided in this register. Higher number corresponds to good quality measurement while a low number indicates lower quality. The value of the quality factor ranges from 0 to 256. The eight most significant bits of register 4 correspond to the 8-bits quality factor from sensor 1 while the eight least significant bits correspond to the quality factor of sensor 2.

Web guide status and fault registers

Bit #	Value	Label	Description
0	0/1	No operator interface	0: if no operator interface is detected 1: if an operator interface is detected
1	0/1	No motor driver	0: if no motor driver is detected

			1: if a motor driver is detected
2	O/1	Motor fault detected	0: if motor motor function is normal 1: if a motor fault is detected
3	O/1	Disturbance detected	0:if no disturbance is detected 1: if a disturbance is detected
4	0/1	Traction issue detected	0: if no traction issue is detected 1: if a traction issue is detected
5	0/1	Upstream misalignment	0: if no upstream misalignment is detected 1: if an upstream misalignment is detected
6	0/1	Guide extreme position	0: if the web guide is within the normal position1: if the web guide is in an extreme position
7	0/1	High frequency disturbance detected	0: if a high frequency disturbance is detected 1: if no high frequency disturbances are detected
8	0/1	Manual/Auto	0: if the web guide is in manual mode 1: if the web guide is in automatic mode
9	0/1	Jog Left operation	0:if the web guide is not jogging left 1: if the web guide is jogging left
10	0/1	Jog Right operation	0: if the web guide is not jogging right 1: if the web guide is jogging right
11	0/1	Servo Centering operation	0: if the web guide is not servo centering 1 if the web guide is servo centering
12	0/1	Good guiding performance	O: if the guiding performance is not good

		1: if the guiding performance is good
13-15	NA	Reserved for future use

Guide point percentage

The guide point for the web guide is provided in this register. 16-bit signed integer guidepoint offset is provided in this register. When the guide point is changed on the screen or through the remote industrial ethernet interface, this register can be used to verify the change.

Actuator speed percentage

The positioning speed of the actuator as a percentage of maximum speed is provided in most significant bits of register 7. The value ranges between 0 and 100.

Actuator acceleration percentage

The acceleration of the actuator as a percentage of maximum acceleration is provided in the least significant bits of register 7. The value ranges between 0 and 100.

Controller Input Registers

Sensor input registers are control registers that are used to control/configure the parameters of each sensor. One 16-bit command register for each sensor is available for an external device to set the sensor parameters. The input registers are mapped as shown below:

Register #	bit 15	bit 14	bit 13	bit 12	bit 11	bit1 0	bit 9	bit 8	bit 7	bit 6	bit 5	bit 4	bit 3	bit 2	bit 1	bit O
0		Sensor 1 command register														
1		Sensor 2 command register														
2		Guide command register														
3		Guide point offset register														
4	EN	Ν	lotor s	peed	perce	ntage	registe	er	EN	Moto	or acce	elerati	on per	centa	ge reg	gister

Sensor Command Register

The bits in the command register are organized as follow:

Bit #	Value	Label	Description
0-1	0, 2 or 3	Sensor orientation	0: set sensor orientation to be right sensor

			Note: If the sensor orientation is left sensor or right sensor then the analog mode selection value of 3 - 6 will have no effect. The analog output would always correspond to the respective orientation. Note: The analog mode 2 has the highest priority followed by mode 1. If any one of the sensors have these bits enabled then the analog output will always provide the high or low output based on the priority. Always disable one sensor while selecting the output for the other sensor.
6	0/1	Find sensor	O: Disable find sensor operation1: Enable find sensor operation by resetting the orientation and allowing the sensor to detect the web orientation.Note: This bit is momentary when set to one. Every time the find sensor operation needs to be enabled the bit needs to be cleared to zero before setting it to one.
7	0/1	Disable Auto Switch	 O: Enable the auto switch functionality for sensor orientation. Find sensor will work only when this is cleared to zero. 1: Disable auto switch functionality so that the sensor orientation can be forced remotely. This bit must be set to one before bit 0 and bit 1 can be changed.
8-15	0-255	Minimum contrast	Minimum contrast: Minimum contrast required to accept an edge in contrast mode Default value is 50.

WARNING: The control of the sensor oriental remotely would not work if the bit 7 is not set to one.

WARNING: The control of the sensor oriental remotely would not work if the analog mode is set to 0. The analog mode can be set to any other value other than 0.

WARNING: If the analog mode is set to 0 then the sensor would be disabled.

Web guide command register

Bit #	Value	Label	Description
0-7	NA		Reserved for future use
8	0/1	Remote control	 0: if cleared to zero, the local operator interface have control over the web guide 1: if set to one, the remote ethernet controller has control over the web guide. The interface icons to control the web guide on the local operator interface will be disabled. Information for monitoring purposes will be displayed on the screen.

9	0/1	Manual/Auto mode	0: if cleared to zero, the web guide will be placed in the manual mode 1: if set to one, the web guide will be placed in the automatic mode
10	0/1	Jog Left or decrease guidepoint	 This bit performs two functions based on bit 9. If bit 9 is cleared: 0: Stop Jog Left operation 1: Start Jog Left operation Note that this register is a write only register and will not change state if the web guide reaches the extreme position. If bit 9 is set: 0: will clear the register and has no effect 1: will decrease the guide point by 0.254 mm or 1/100th of an inch from the current value. Note that this value on this register is momentary. Before decreasing the guidepoint the bit needs to be cleared before setting it to one. Note that the guide point cannot be at the extremes of the sensing window and will automatically be truncated if the extreme limit is reached. The extreme limit depends on the sensor resolution and sensor width.
11	0/1	Jog Right or increase guidepoint	 This bit performs two functions based on bit 9. If bit 9 is cleared: O: Stop Jog Right operation 1: Start Jog Right operation Note that this register is a write only register and will not change state if the web guide reaches the extreme position. If bit 9 is set: O: will clear the register and has no effect 1: will increase the guide point by 0.254 mm or 1/100th of an inch from the current value. Note that this value on this register is momentary. Before increasing the guidepoint the bit needs to be cleared before setting it to one. Note that the guide point cannot be at the extremes of the sensing window and will automatically be truncated if the extreme limit is reached. The extreme limit is set such that at least ±3.175 mm is available on either side of the adjusted guide point.
12	0/1	Servo Center operation or set guide point	 This bit performs two functions based on bit 9. If bit 9 is cleared: 0: No effect 1: Start Servo Center operation Note that this register is a write only register and will not change state if the web guide reaches the center position. Note that this value on this register is momentary. Before a servo center operation the bit needs to be cleared to zero before setting it to one. If bit 9 is set: 0: will clear the register and has no effect

			• 1: will set the guide point to be at 50% of the sensing window. Note that this value on this register is momentary. Before decreasing the guidepoint the bit needs to be cleared before setting it to one. The extreme limit is set such that at least ±3.175 mm is available on either side of the adjusted guide point.
13	0/1	Enable arbitrary gross guide point adjustment	This bit allows arbitrary gross adjustment of the guide point offset through the industrial ethernet interface. O: if cleared to zero, gross guide point adjustment is disabled 1: if set to one, the remote ethernet controller can make arbitrary gross adjustment to the guide point by writing a 16-bit signed integer to the guide point register.
14-15	NA		Reserved for future

WARNING: All the remote control operations may cause the web guide to move without operator intervention. This process may cause process upsets. Caution must be exercised when performing these functions and should be done by those who completely understand the consequence of this change.

WARNING: Web Guiding System enabled by SCU5 controller is an automatic control device that may stop and start at any time without notice, especially when controlled remotely. Hence standard safeguards must be in place to prevent any kind of injury.

WARNING: The remote control options provide significant access and control of the web guide and the sensor. A combination of the settings may create conditions that might not be ideal for web guiding. Hence only personnel familiar with the web guide operation should program the remote control interface. Contact Roll-2-Roll Technologies' technical support team for any question or assistance.

Guide point offset register

If the 13th bit of the web guide command register is set, then arbitrary guide point adjustment can be made by writing a 16-bit signed integer value to the guide point offset register. The offset value is the distance from the desired guide point location to the middle of the sensor window. A positive offset value will result in a guide point location towards the right half of the sensor window while a negative offset will result in a guide point location towards the left half of the sensor window. The guide point offset in mm = 0.0635*(the 16-bit guide point offset register).

Actuator speed register

The positioning speed of the actuator can be changed by setting the 15th bit of the register to 1 and writing a value between 0 and 100 in 7 remaining most significant bits. If the 15th bit is low then the value written in the remaining 7 most significant bits will be ignored.

Actuator acceleration register

The acceleration of the actuator can be changed by setting the 7th bit of the register to 1 and writing a value between 0 and 100 in the 7 least significant bits. If the 7th bit is low then the value written in the register is being ignored.

Communication Module

Off-shelf industrial ethernet modules from <u>HMS industrial</u>, are used in the SCU5 controller to provide ethernet connectivity. A 4-pin D-coded M12 socket connect is provided for ethernet connection. Standard network cables can be used to connect the SCU5 MC(x) to an ethernet network using RJ45 plug.

IP Address

The SCU5 MC(x) is configured to automatically acquire an IP address from a DHCP router or a server. As soon as the controller is connected to a network, an IP address is automatically assigned to the device. Before starting the configuration procedure find the IP address of the controller on the network.

Finding the IP Address

Once the controller is powered ON, the controller will automatically connect to the network. The controller is configured to get the IP address automatically from a DHCP server. Hence the controller should be connected to a network where dynamic IP addresses are issued by a network device such as a router.

A network port scan utility can be used to find the controller. Alternatively the <u>IPConfig</u> utility available in the software section of the <u>HMS Industrial website</u> can be used to scan for the device.

Once the utility is installed the program can be run to find the AnyBus IC module on the SCU5 MC(x). The following shows the opening screen of the IPconfig utility.

IPconfig	1					<u>.</u>		>
P	SN	GW	DHCP	Version	Туре	MAC		
					Settings	[Scan]	E	xit

By pressing the scan button all the devices on the network from HMS Industrial network can be found. For example, the utility would find the device and list it as shown below.

IPconfig	1						is - si		>
IP	7	SN	GW	DHCP	Version	Туре	MAC		
192.168.1.1	112	255.255.255.0	192.168.1.1	On	3.12.1	Anybus-IC EtherNet	00-30-1	1-16-B2-F0	

Information such as IP address, DHCP state, Type of module and the MAC address is displayed.

Setting a static IP address for the controller

Double clicking on the desired device listed in the IPConfig window would bring a screen to configure the Static/Dynamic IP address setting as shown below. By selecting the DHCP setting to be off, static IP address can be configured for the device.

IPconfig	Configure: 00-30-	11-16-B2	-F0			× 🗆 >
	Ethernet configuration	n				
92.168.1.112	IP address:	<u>_</u> .		<u>_</u>		B2-F0
	Subnet mask:					
	Default gateway:	s	÷	<i></i>		
	Primary DNS:]	
	Secondary DNS:				1	
	Hostname:					
	Password:				Change password	
	New password:					
					Set Cancel	Exit

IPconfig	Ethernet configuration		>
D 7	IP address: 192 . 168 . 1 . 120		1
92.168.1.11	Subnet mask: 255 255 255 0	C On 82-F0	
		● Off	
	Default gateway: 192 . 168 . 1 . 1		
	Primary DNS:		
	Secondary DNS:		
	Hostname:		
	Password:	Change password	
	New password:		

By clicking on the "Set" the static IP address can be set. Once the static IP address is set the IPconfig utility will refresh to show the new configuration. The DHCP setting will be set to "OFF" state and the new IP address will be assigned to the device as shown below.

I IPconfig								×
IP /	SN	GW	DH	Version	Туре	MAC		
192.168.1.120	255.255.255.0	192.168.1.1	Off	3.12.1	Anybus-IC EtherNet/IP(TM)	00-30-1	1-16-B2-FC)

Adding an EtherNet/IP module in Rockwell/AB Ecosystem

Open Studio 5000 project for the PLC that needs to be connected to the SCU5 C(E) controller. Locate the Ethernet module in the I/O configuration of the controller organizer. Select the Ethernet module and right click to add a new module:

In the search box type "ethernet-module", to add a generic ethernet module.

ethernet-module	Clear Filters		Show Filters
Catalog Number	Description	Vendor	Category
ETHERNET-MODULE	Generic Ethernet Module	Allen-Brad	Communic

Configuring the module parameters

Once selected a property box will pop-up. In the property box, the name and description fields can be chosen arbitrarily. The communication data format MUST be changed to Data-INT in the drop down menu. The IP address MUST match the IP address of the sensor on the network. The connection parameters MUST match the one shown on the image below:

THERNET-MODULE Generic Ethern	et Module			
Allen-Bradley				
ocal				
ArisWPS	Connection Para	meters Assembly		
Ethernet module for the		Instance:	Size:	
communication with ARIS web	Input:	100	8	(16-bit)
× .	Output:	150	8	(16-bit)
Data - INT 🗸 🗸 🗸	Configuration	1	0	(8 bit)
Name	Configuration.		Ľ	
i: 192 . 168 . 0 . 102	Status Input:			
2:	Status Output:			
	ArisWPS Ethernet module for the communication with ARIS web position sensor Data - INT Name 192 . 168 . 0 . 102 e:	ArisWPS Ethernet module for the ommunication with ARIS web position sensor Data - INT Data - INT Name 192 . 168 . 0 . 102 Status Input: Status Output: Status Output:	Assembly Ethernet module for the communication with ARIS web nosition sensor Data - INT Name 192 . 168 . 0 . 102 e: Image: Status Output:	Assembly Ethernet module for the oommunication with ARIS web oosition sensor Data - INT Name :: 192 168 0 :: 192 168 0 :: 192 168 :: Status Output:

In the connection parameters choose the input assembly instance to start at 100 with a size of 8 (16-bit), output to start at 150 with a size of 8 (16-bit) and the configuration to 1 with a size of 0. Check "Open Module Properties" and press OK.

Configuring communication options

The next step involves the communication option configuration. The RPI sets the frequency at which the data is exchanged, lower RPI would imply a higher network load and vice versa. The sensor updates the data every 20ms, therefore any RPI lower than that would not result in any extra meaningful data. Set the RPI to be 20 ms.

Module Properties Report: Local (ETHERNET-MODULE 1.001)	
General Connection* Module Info	
Requested Packet Interval (RPI): 20.0 ms (1.0 - 3200.0 ms) Inhibit Module Major Fault On Controller If Connection Fails While in Run Mode Use Unicast Connection over EtherNet/IP	
Module Fault	
Status: Offline OK Cancel Apply Help	

Click "Apply" to add the module.

Importing Add-On-Instruction

Roll-2-Roll Technologies provides an Add-On-Instruction (AOI) to easily interface the sensor as well as the web guide. To import the AOI: select the Add-On Instruction in the controller organizer, right click and select import Add-On Instruction:

Controller Organizer			•	џ	×
🗏 🔤 Tasks					^
🖻 🚭 Main Task					
🗄 🗣 MainProgram					
Unscheduled					
🗏 🔤 Motion Groups					
Ungrouped Axes					
- Add-On Instructions					
🗏 🔤 Data Types	6	New Add-On Instruction.			
📲 User-Defined		Import Add-On Instruction	n		
📲 Strings					
- 🛱 Add-On-Defined	X	Cut		Ctr	+X
🗄 🖼 Predefined	Đ	Сору		Ctr	I+C

For example, importing the AOI for sensor is shown in the following.

	itHub > KOIOS-ICS >	v ₽	Search KOIOS-ICS	Q
Organize • New fold	der			?
Projects	Name		Date modified	Тур
left ConeDrive	📜 build		12/1/2016 11:50 AM	1 File
This DC	🦲 debug		12/14/2016 9:21 AN	1 File
	🧵 dist		12/1/2016 11:50 AM	1 File
E Desktop	📕 nbproject		12/15/2016 11:18 A	M File
Documents	ARIS_SensorInterface.L5	х	12/15/2016 3:55 PN	1 Lo
👃 Downloads				
🔈 Music				
E Pictures				
Videos				
🐛 Windows8_OS ((
LENOVO (D:)				
~	<			>
File n	ame: ARIS_SensorInterface.L5X	~	Logix Designer XML Files (*.L5	X, ~

Select the ARIS_SensorInterface.L5X file provided by Roll-2-Roll Technologies.

Once imported the AOI logic and user defined variables will appear in the controller organizer:

Using SCU5 C(E) Add-On Instruction

Once imported, AOI will appear in the Add-on tab from which it can be added to the project.

Once dropped in a rung simply fill the variables in the AOI.

Note: the ARIS_Input and ARIS_Output variable MUST match the variable of the ARIS Ethernet module.

All other variable can be named arbitrarily. In this example the ARIS_Input is mapped to ARIS_WPS:I.Data and ARIS_Output is mapped to ARIS_WPS:O.Data.

Sensor variables

SCU5 C(E) sensor variables are defined to make the integration of the sensor easy for the user without having to worry about the mapping and decoding the input and output registers. There are two types of variables: ARIS_FromWebEdgeSensorVar and ARIS_ToWebEdgeSensorVar. The first one contains all the data coming from the sensor, the second all the data that can be sent to the SCU5 C(E) to control the sensor. The sensor related data coming from the controller is read from the sensor output registers. The image below shows an instance of the ARIS_FromWebEdgeSensorVar variable with all the available fields. In this instance FromRewindEdgeSensor is the name of the variable of type ARIS_FromWebEdgeSensorVar. The PLC program can uses these variables to monitor the status/fault as well as obtain the measurement information from the sensor.

-	FromRewindEdgeSensor	{}	{		ARIS_Fro
	FromRewindEdgeSensor.NoSensor	0		Decimal	BOOL
	FromRewindEdgeSensor.LowContrast	0		Decimal	BOOL
	FromRewindEdgeSensor.NoWeb	0		Decimal	BOOL
	FromRewindEdgeSensor.WorngOrie	0		Decimal	BOOL
	FromRewindEdgeSensor.Flutter	0		Decimal	BOOL
	FromRewindEdgeSensor.LeftSensor	0		Decimal	BOOL
	FromRewindEdgeSensor.RightSensor	0		Decimal	BOOL
	+ FromRewindEdgeSensor.NumberOfP	0		Decimal	INT
	+ FromRewindEdgeSensor.SensorMode	0		Decimal	INT
	+ FromRewindEdgeSensor.EdgePixel	0		Decimal	DINT
	FromRewindEdgeSensor.Edge_mm	0.0		Float	REAL
	FromRewindEdgeSensor.QualityFactor	0		Decimal	INT

The image below shows an instance of the ARIS_ToWebEdgeSensorVar which can be used in the PLC program to control/command the sensor through the SCU5 C(E).

ToRewindEdgeSensor	{}	{		ARIS_ToE
ToRewindEdgeSensor.ForceRightSe	0		Decimal	BOOL
ToRewindEdgeSensor.ForceLeftSen	0		Decimal	BOOL
ToRewindEdgeSensor.FindSensor	0		Decimal	BOOL
ToRewindEdgeSensor.AutoSwitchOff	0		Decimal	BOOL
+ ToRewindEdgeSensor.SensorMode	0		Decimal	INT
ToRewindEdgeSensor.OutputDis	0		Decimal	BOOL
	ToRewindEdgeSensor Image: Content of the system ToRewindEdgeSensor.ForceRightSe Image: Content of the system ToRewindEdgeSensor.ForceLeftSen Image: Content of the system ToRewindEdgeSensor.FindSensor Image: Content of the system ToRewindEdgeSensor.AutoSwitchOff Image: Content of the system ToRewindEdgeSensor.SensorMode Image: Content of the system ToRewindEdgeSensor.OutputDis Image: Content of the system	ToRewindEdgeSensor {} ToRewindEdgeSensor.ForceRightSe 0 ToRewindEdgeSensor.ForceLeftSen 0 ToRewindEdgeSensor.FindSensor 0 ToRewindEdgeSensor.AutoSwitchOff 0 ToRewindEdgeSensor.SensorMode 0 ToRewindEdgeSensor.OutputDis 0	ToRewindEdgeSensor {} ToRewindEdgeSensor.ForceRightSe 0 ToRewindEdgeSensor.ForceLeftSen 0 ToRewindEdgeSensor.FindSensor 0 ToRewindEdgeSensor.AutoSwitchOff 0 ToRewindEdgeSensor.SensorMode 0 ToRewindEdgeSensor.OutputDis 0	ToRewindEdgeSensor {} ToRewindEdgeSensor.ForceRightSe 0 ToRewindEdgeSensor.ForceLeftSen 0 ToRewindEdgeSensor.ForceLeftSen 0 ToRewindEdgeSensor.FindSensor 0 ToRewindEdgeSensor.ForceLeftSen 0 ToRewindEdgeSensor.FindSensor 0 ToRewindEdgeSensor.AutoSwitchOff 0 ToRewindEdgeSensor.SensorMode 0 ToRewindEdgeSensor.OutputDis 0

COMMISSIONING

Sensing and Measurement Application

Depending on the application one or two sensors may need to be connected to the controller. Using the functionality described in the previous section, the output of the controller should be configured appropriately. Once the settings are configured, the user need not interact with the controller at all. The only interaction required will be for contrast setup functionality. The screen can be used for monitoring purposes. Please refer to the installation checklist and the sensor installation recommendation documents on the respective sensor product page on the web site.

Web Guiding Application

A properly installed web guide requires correct threading of the web over the guide rollers and initial positioning of the sensor based on the desired position of the web to provide optimum performance. Once the material is threaded over the guide rollers and the sensor has been properly positioned, all the operator has to do is to press the automatic operation icon on the operator interface. Please refer to the respective sensor and web guide manual for proper installation of the web guiding system.

The following section describes the steps and conditions required for automatic operation with a SCU5 M web guide controller.

Edge Guiding

- 1. Power ON the system
- 2. Automatic/Manual operation set to "Manual" (Automatic/Manual icon pressed to red)
- 3. Press the Servo-Center button to center the guide rollers.
- 4. Thread the material over the rollers. The material wrapped over the rollers must be at a 90 degree angle both at the entry and exit of the guide rollers.
- 5. Verify that the material is aligned in the desired position with respect to the upstream and downstream position of the web. Place the web under normal operation tension.
- 6. Adjust sensor position on the desired edge of the web. Then manually position the sensor so that the edge of the web is at the middle of the sensing window. This can be done by observing the web edge position indicator on the display. When the bar is in the middle position then the web edge is in the middle of the sensing window.
- 7. If the sensor position indicator and the actual position of the sensor are different then press the "Find Sensor" button on the operator interface so that the controller automatically finds the correct orientation of the edge sensor. In order for this function to work the web edge needs to be in the middle of the sensing window.
- 8. Tighten the sensor thumbscrews or the brake on the sensor to secure the sensor position on the sensor rail.
- 9. Press the Automatic/Manual operation icon to "Automatic" (Automatic/Manual icon pressed to green).
- 10. The guide will automatically adjust the position of the web material to guide it to the correct position.

Center Guiding Application

For center guiding application follow the same steps for each sensor before enabling the automatic guiding mode.

Standard Operating Procedure

The standard operating procedure for the web guide controller involves the following steps.

- 1. During startup or change over, servo center the web guide to its home/middle position.
- 2. Thread the web at the desired location on the web guide rollers.
- 3. If the guide point offset is not needed then clear the guide point offset to zero, else reset the guide point to the current web location.
- 4. For edge guiding applications, position the sensor such that the web aligns with the guide point location on the screen.
- 5. If manual positioning of the sensor is not desired, use the reset guide point operation to digitally move the guide point to the current web position. This is mostly applicable with wide sensors when the new location of the web is still within the sensing window of the sensor.
- 6. If the web is guided to the center line position, reset the guide point to the current location of the web while ensuring that both edges are seen by the sensors.
- 7. Set the web guide in automatic mode.
- 8. If during operation fine adjustments to the guide point are needed, then use the fine guide point adjustment procedure to make the necessary changes while the web guide is in automatic mode. The effect of the guide point adjustment will be seen only when the web is moving.
- 9. Once the line is stopped for changeover or production stoppage, set the web guide to manual mode and if needed servo center the web guide to its home/middle position.

General Maintenance

There is no general maintenance required for the web guide controller. Please refer to the respective sensor and web guide manual for maintenance information.

TECHNICAL SUPPORT AND SERVICE

Contact information

Roll-2-Roll Technologies LLC is dedicated to providing exceptional service and support to its customers. Please feel free to contact us for any technical support, installation support and service requirements.

Roll-2-Roll Technologies LLC 1110 S Innovation Way Dr Stillwater, OK 74074 Website: https://r2r.tech

Technical Support Phone: +1 (888) 290-3215 - ext 3 General Support Phone: +1 (888) 290-3125 - ext 1

Technical Support Email: engineering@r2r.tech General Support Email: support@r2r.tech

Return shipping instructions

Please contact us to obtain a return merchandise authorization (RMA) number before returning the product to us. If returning the product, please follow the instructions on the RMA form for quick and efficient service.

REVISION HISTORY

Document Revision

Version	Date	Changes
1.0	Sep 2015	Initial Release Version
1.1	Feb 2016	Comprehensive revision and new sections added: safety instructions, mounting dimensions, troubleshooting, specifications.
2.0	Jun 2016	Updated documentation for SCU V4 Rev D hardware, firmware and OI.
2.2	Dec 2016	Updated documentation for firmware updates and usability changes
2.4	Jun 2017	Updated documentation for firmware updates and operator interface changes
2.6	Nov 2018	Updated documentation for firmware updates and operator interface changes
3.3	Dec 2018	Updated documentation for contrast sensor capabilities
3.3	Jun 2019	Updated documentation with static and dynamic thresholding.
3.4	Aug 2019	Updated documentation for firmware version 3.4 with significant advances.
3.4	Mar 2020	Corrected the ethernet input register map.

Hardware Revision

Version	Date	Description
SCU V2	Dec 2014	Initial version with 12 VDC input
SCU V3	Jun 2015	Expanded version with 24 VDC input
SCU V4 Rev B	Oct 2015	Two sensor option, WDT, RTCC
SCU V4 Rev C	Mar 2016	Analog Output
SCU V4 Rev D	July 2016	Industrial ethernet option
SCU5 Rev B	May 2017	Smaller form factor board
SCU5 Rev C	Nov 2017	Robustness improvements

Firmware Revision

Version	Date	Description
1.0	Jan 2015	Initial version, single sensor
1.1	Aug 2015	Firmware update for SCU V3, automatic sensor state detection
1.2	Nov 2015	Firmware update for SCU V4 Rev B. Modified sensor algorithm to increase precision and accuracy.
1.3	Dec 2015	Two sensor option with automatic pixel detection
1.4	Mar 2016	Background suppression algorithm
1.5	Apr 2016	Analog output
2.1a	Aug 2016	Firmware update for SUC V4 Rev D
2.2b	Dec 2016	Ethernet/IP implicit messaging, edge detection algorithm updates
2.4a	Jun 2017	Changes to guide point adjustment and Ethernet/IP registers
2.5	Apr 2018	Minor bug fixes, enabled password protected screen
2.6	Nov 2018	Provided more access to internal settings of the controller for power users.
3.3	Dec 2018	Updated functionality to version 3 algorithm.
3.3c	Jan 2019	Updated functionality to include minimum contrast setting.
3.3d	Jun 2019	Added functionality for both static and dynamic thresholding.
3.4	Jul 2019	Significant update with added functionality for power user access and for built in width measurement application.
3.4a	Aug 2019	Added the ability to view and change the ethernet network settings from the SCU5 controller communication screen.
3.4b	Mar 2020	Improvements to edge detection algorithms and improved processing speed.

Roll-2-Roll Technologies LLC 1110 S Innovation Way Dr Stillwater, OK 74074 www.r2r-tech.com

info@r2r-tech.com +1-(888)-290-3215